




The EGADS API
Engineering Geometry Aircraft Design System
at ESP Revision 1.29

Bob Haimes
haimes@mit.edu
Geocentric Technologies LLC
&
Massachusetts Institute of Technology



● Overview	4
● EGADS Objects	
● Geometry	16
● Topology	30
● <i>Effective Topology</i>	37
● Tessellation	40
● The Model	44
● Others	45
● EGADS & EGADSLite API	
● Utility & IO Functions	51
● Attribution	64
● Geometry	73
● Topology	88
● Tessellation	112
● Top-Down Build Functions	138
● <i>Effective Topology</i>	152
● API Index	157

Provide a “bottom up” and/or Constructive Solid Geometry foundation for building Aircraft (or other mechanical devices)

- Built upon OpenCASCADE
 - Open Source solid modeling geometry kernel
 - Support for manifold and non-manifold geometry
 - Reading & writing IGES, STEP and native formats
 - C++ with ~17,000 methods!
- Open Source (LGPL v2.1)
- C/C++, FORTRAN, Python and Julia Interfaces
 - Single API with minor variations for FORTRAN
 - Always returns an integer code (success/error condition)
 - Requires C pointer access in FORTRAN
 - Cray-pointer construct –or–
 - C-pointers (2003 extension to FORTRAN 90)
 - Both supported by Intel FORTRAN and gfortran
 - API contains memory functions

System Support

- **macOS** with clang, ifort and/or gfortran
- **LINUX** with gcc, ifort and/or gfortran
- **Windows** with Microsoft Visual Studio C++ and ifort
- No global variables and thread-safe
- Various levels of verbose output (0-none, through 3-debug)
- Written in C and C++
- Fortran bindings written in C
- pyEGADS requires no other dependencies other than a current version of Python
- jlEGADS requires Julia v1.6 or greater

EGADS Objects

- Treated as “blind” pointers – an **ego**
 - Allows for an *Object-based* programming model
 - Can access internals in C/C++
- Context Object holds *global* information
- **egos** have:
 - *Owner*: Context, Body, EBody, or Model
 - Reference Objects (objects they depend upon)
- **egos** are INTEGER*8 variables in FORTRAN
 - Allows for same source code regardless of size of pointer
 - Requires “freeing” of internal lists of objects (not for C/C++)

The Context Object and Threads

- When a Context Object is created (`EG_open` – page 51) the calling thread ID is saved within the Context
- Any construction functions or functions that change the attribute storage must be done from the thread stored in the Context
- The Context's thread may be modified by invoking `EG_updateThread` (page 56) called from the new thread

MultiThreading

- After a thread is spawned, it can call `EG_open` (page 51) to setup a Context to use with the thread
 - Will work with native threads, ESP's EMP package or *OpenMP*
- Use `EG_copyObject` (page 58) to copy an object from its owning Context to the target Context specified in the 2nd argument
- Use `EG_contextCopy` (page 59) to copy an object to the target Context specified by the 1st argument

See [\\$ESP_ROOT/src/EGADS/examples/multiContext.c](#) for an example using EMP

EGADSlite – for HPC Environments

- No construction supported
- Same API and Object model as EGADS
 - Can use EGADS to prototype/build EGADSlite code
- Suitable for MPI
 - From EGADS via a *stream*, see EG_exportModel – page 62
 - To EGADSlite from the *stream*, see EG_importModel – page 62
 - *Stream* setup to Broadcast (or write to disk)
- ANSI C – No OpenCASCADE
- Tiny memory footprint
- Thread safe and scalable
 - EGADS' OpenCASCADE evaluation functions replaced with those written for EGADSlite

See [\\$ESP_ROOT/externApps/Pagoda/EGADSServer](#) for an MPI example

- Context – Holds the *globals*
- Transform
- Tessellation
- Nil (allocated but not assigned) – internal
- Empty – internal
- Reference – internal
- Geometry
 - pcurve, curve, surface
- Topology
 - Node, Edge, Loop, Face, Shell, Body, Model
- *Effective Topology*
 - EEdge, ELoop, EFace, EShell, EBody

See [\\$ESP_ROOT/include/egadsTypes.h](#) for a list of defines

C structure definition - an ego

```
typedef struct egObject {  
    int      magicnumber;      /* must be properly set to validate  
                               the object */  
  
    short    oclass;           /* object class */  
    short    mtype;           /* object member type */  
    void     *attrs;           /* attributes or reference */  
    void     *blind;           /* blind pointer to OpenCASCADE or  
                               EGADS data */  
  
    struct egObject *topObj;    /* top of the hierarchy or  
                               context (if top) */  
  
    struct egObject *ref;       /* threaded list of references */  
    struct egObject *prev;      /* back pointer */  
    struct egObject *next;      /* forward pointer */  
} egObject;  
#define ego egObject*
```

Context Object

- Start of dual threaded-list of active egos
- Pool of deleted objects

Attribution Modes

- Single [default] – One attribute on an Object can have the **name**
- Full – There can be any number of attributes with the same **name**

Attributes

- Are identified by a **name** (character string with no spaces or other special characters)
- Each attribute has a single **type**:
 - Integer
 - Real (double precision)
 - String (can have spaces and other special characters)
 - CSys – Coordinate System (uses the Real storage)
 - Ptr – Supplied pointer (not persistent and the programmer is responsible for memory management, i.e. freeing the storage). Uses the String pointer.
- And a **length** (for Integer, Real and CSys types)

Objects & Attributes

- Any Object (except for Reference) may have multiple Attributes
- Only Attributes on Topological Objects are copied (except for Pointers)
- Only Attributes on Topological, *Effective* and Tessellation Objects are persistent (except for Pointer Types) – and this is available only through “.egads” file IO.

SBOs and Intersection Functions

- Attributes on Faces will be carried through to the resultant fragments after intersections (except for Pointer types)
- Unmodified Topology maintains their attributes (except for Pointers)

More Complex Associations

From `EG_filletBody`, `EG_chamferBody` and `EG_hollowBody` a list is returned containing an *operation* and an index to a source object in the Body:

<i>operation</i>	Description
NODEOFF (1)	The Face is the result of a Node – the index is that of the Node in the source Body
EDGEOFF (2)	The Face is the result of an Edge – the index is the Edge index (see <code>EG_indexBodyTopo</code> , page 97)
FACEDUP* (3)	The Face is an exact copy of the source
FACECUT* (4)	The Face has been trimmed or split from the source
FACEOFF (5)	The Face is offset from the source Face – the index is that of the source

* Note: this information is redundant with the use of Face attribution

Coordinate Systems – ATTRCSYS

- Input Reals must be one of:
 - Any Object may have 9 values
 - position[†], first direction[†], second direction[†]
 - FACE/SURFACE can also have 6 or 3 values
 - u, v, flip, second direction[†] (first direction is flip*normal)
 - u, v, *idir*: 1 – udir, 2 – vdir, 3 – -udir, 4 – -vdir
first direction is the normal, second is set by *idir*
if *idir* is negated then the normal direction is flipped
 - EDGE/CURVE can have 5 values
 - t, flip, second direction[†] (first direction is flip*tangent)
 - NODE can have 6 values
 - first direction[†], second direction[†]
- Output is the position and 3 orthonormal directions
 - 12 doubles returned after the input values or `egads.cs.system.ortho[4][3]` for `EG_attributeGet` (page 67) and `EG_attributeRet` (page 66)

Notes:

- 1 third direction is implied by first \times second
- 2 [†] transformed when object has been transformed
- 3 The actual number of doubles is the attribute length above + 12

Full Attribution – not the default mode

- 1 Edge and Node attributes are tracked through EGADS operations.
- 2 Multiple attributes with the same **name** are maintained. This did not matter in the default scheme because rarely did Faces have this issue, and when it did happen, the attributes from the “tool” of SBOs were used.
- 3 To track multiple (same **name**) attributes attached to an object with different values, a sequence number is internally added to the **name**. In the past the **name** of the attribute could not have spaces, so a space is used as the delimiter.
- 4 When merging attributes with the same **name**:
 - a) If there is only a single attribute with the **name** and the value on the proposed merged attribute is the same then there is no merge/addition.
 - b) If the values are different, then the **name** of the existing attribute is appended with “ 1” and the **name** of the added attribute is appended the sequence number “ 2”. That is, an attribute **name** without a sequence number can only exist with a single attribute of that **name**.
 - c) If there are already multiple sequences for the same **name**, any additional merges adds the attribute and bumps the sequence –unless–
 - d) Any attribute merge that has the same value as an existing attribute (of the same **name**) will not be added. This is consistent with (4a) above for the single (non sequenced) attribute.
- 5 Sequence numbers always start with 1 and go to the number of attributes sharing that **name**. You will not find a single attribute with a sequence number (the sequence number extension will be removed by EGADS).

oclass = PCURVE – Parameter Space Curves

- 2D curves in the Parametric space $[u, v]$ of a surface
- Types: Line, Circle, Ellipse, Parabola, Hyperbola, Trimmed, Bezier, BSpline, Offset
- All types abstracted to $[u, v] = g(t)$

oclass = CURVE

- 3D curve – single running parameter (t)
- Types: Line, Circle, Ellipse, Parabola, Hyperbola, Trimmed, Bezier, BSpline, Offset
- All member types abstracted to $[x, y, z] = g(t)$

oclass = SURFACE

- 3D surfaces of 2 parameters $[u, v]$
- Types: Plane, Spherical, Cylindrical, Revolution, Toriodal, Trimmed, Bezier, BSpline, Offset, Conical, Extrusion
- All types abstracted to $[x, y, z] = f(u, v)$

Detailed Geometry

- Geometry is created by invoking `EG_makeGeometry` (page 73)
- Geometry is queried via calls to `EG_getGeometry` (page 74)
- The information is always a pointer to **doubles** with an optional pointer to **ints** – the lengths required are described below
- Some member types require an **ego** as a reference
- Analytic derivatives exist for many Geometry functions – see [\\$ESP_ROOT/doc/EGADS/EGADS_dot/EGADS_dot.pdf](#)

mtype = LINE

data length \Rightarrow	PCurve – 4	Curve – 6
Location	$[u, v]$	$[x, y, z]$
Direction	$[dir_u, dir_v]$	$[dir_x, dir_y, dir_z]$

mtype = CIRCLE

data length \Rightarrow	PCurve – 7	Curve – 10
Center	$[u, v]$	$[x, y, z]$
Xaxis	$[xax_u, xax_v]$	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_u, yax_v]$	$[yax_x, yax_y, yax_z]$
Radius		

note: Xaxis and Yaxis should be orthogonal

mtype = ELLIPSE

data length \Rightarrow	PCurve – 8	Curve – 11
Location	$[u, v]$	$[x, y, z]$
Xaxis	$[xax_u, xax_v]$	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_u, yax_v]$	$[yax_x, yax_y, yax_z]$
MajorRadius		
MinorRadius		

note: Xaxis and Yaxis should be orthogonal

mtype = PARABOLA

data length \Rightarrow	PCurve – 7	Curve – 10
Location	$[u, v]$	$[x, y, z]$
Xaxis	$[xax_u, xax_v]$	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_u, yax_v]$	$[yax_x, yax_y, yax_z]$
Focus		

note: Xaxis and Yaxis should be orthogonal

mtype = HYPERBOLA

data length \Rightarrow	PCurve – 8	Curve – 11
Location	$[u, v]$	$[x, y, z]$
Xaxis	$[xax_u, xax_v]$	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_u, yax_v]$	$[yax_x, yax_y, yax_z]$
MajorRadius		
MinorRadius		

note: Xaxis and Yaxis should be orthogonal

mtype = TRIMMED

data length \Rightarrow	PCurve – 2	Curve – 2
Range	$t\text{-start}, t\text{-end}$	$t\text{-start}, t\text{-end}$

note: Requires reference geometry of same class (PCURVE or CURVE)

mtype = OFFSET

data length \Rightarrow	PCurve - 1	Curve - 4
Direction Offset	—	$[dir_x, dir_y, dir_z]$

note: Requires reference geometry of same class (PCURVE or CURVE)

mtype = BEZIER

int [3]	Description
Bit Flag	2 – rational, 4 – periodic
Degree	nCP-1 up to 25 (not used on input)
nCP	number of control points

doubles	PCurve	Curve
Control Points	2*nCP	3*nCP
Weights*	nCP	nCP

* note: Weights exist only if rational

mtype = BSPLINE (includes NURBS)

int [4]	Description
Bit Flag	2 – rational, 4 – periodic
Degree	
nCP	
nKnots	
	number of control points
	number of knots

doubles	PCurve	Curve
Knots	nKnots	nKnots
Control Points	2*nCP	3*nCP
Weights*	nCP	nCP

* note: Weights exist only if rational

mtype = PLANE

data length \Rightarrow	9
Location	$[x, y, z]$
Xaxis	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_x, yax_y, yax_z]$

note: Xaxis and Yaxis should be orthogonal

mtype = SPHERICAL

data length \Rightarrow	10
Center	$[x, y, z]$
Xaxis	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_x, yax_y, yax_z]$
Radius	

notes:

- 1 Xaxis and Yaxis should be orthogonal
- 2 negative Radius indicates a left-handed coordinate system

mtype = CONICAL

data length \Rightarrow	14
Location	$[x, y, z]$
Xaxis	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_x, yax_y, yax_z]$
Zaxis	$[zax_x, zax_y, zax_z]$
Angle	
Radius	

notes:

- 1 Xaxis and Yaxis and Zaxis should all be orthogonal
- 2 Zaxis is the rotation axis and may be left-handed
- 3 Angle is in radians from 0 to $\pi/2$

mtype = CYLINDRICAL

data length \Rightarrow	13
Location	$[x, y, z]$
Xaxis	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_x, yax_y, yax_z]$
Zaxis	$[zax_x, zax_y, zax_z]$
Radius	

notes:

- 1 Xaxis and Yaxis and Zaxis should all be orthogonal
- 2 Zaxis is the rotation axis and may be left-handed

mtype = EXTRUSION

data length \Rightarrow	3
Direction	$[dir_x, dir_y, dir_z]$

note: requires reference geometry of class CURVE

mtype = TOROIDAL

data length \Rightarrow	14
Center	$[x, y, z]$
Xaxis	$[xax_x, xax_y, xax_z]$
Yaxis	$[yax_x, yax_y, yax_z]$
Zaxis	$[zax_x, zax_y, zax_z]$
MajorRadius	
MinorRadius	

notes:

- ① Xaxis and Yaxis and Zaxis should all be orthogonal
- ② Zaxis is the rotation axis and may be left-handed

mtype = REVOLUTION

data length \Rightarrow	6
Center	$[x, y, z]$
Axis	$[axi_x, axi_y, axi_z]$

note: requires reference geometry of class CURVE

mtype = TRIMMED

data length \Rightarrow	4
uRange	$[u_{min}, u_{max}]$
vRange	$[v_{min}, v_{max}]$

note: requires reference geometry of class SURFACE

mtype = OFFSET

data length \Rightarrow	1
distance	

notes:

- 1 requires reference geometry of class SURFACE
- 2 Offset distance is applied normal to the reference

mtype = BEZIER

int [5]	Description
Bit Flag	2 – rational, 4 – uPeriodic , 8 – vPeriodic
uDegree	nCPu-1 up to 25 (not used on input)
nCPu	number of control points in the u direction
vDegree	nCPv-1 up to 25 (not used on input)
nCPv	number of control points in the v direction

doubles	packed data
Control Points	$3 * nCPu * nCPv$
Weights*	$nCPu * nCPv$

* note: Weights exist only if rational



mtype = BSPLINE (includes NURBS)

int [7]	Description
Bit Flag	2 – rational, 4 – uPeriodic , 8 – vPeriodic
uDegree	the degree of the BSpline in the u direction
nCPu	number of control points in u
nUKnots	number of knots in u
vDegree	the degree of the BSpline in the v direction
nCPv	number of control points in v
nVKnots	number of knots in v

doubles	packed data
uKnots	3*nCPu*nCPv nCPu*nCPv
vKnots	
Control Points	
Weights*	

* note: Weights exist only if rational

Boundary Representation – BRep

<div> <i>Top</i> <i>Down</i>   <i>Bottom</i> <i>Up</i> </div>	Topological Entity	Geometric Entity	Function
	Model		
	Body	Solid, Sheet, Wire	
	Shell		
	Face	surface	$(x, y, z) = \mathbf{f}(u, v)$
	Loop	pcurves*	
	Edge	curve	$(x, y, z) = \mathbf{g}(t)$
	Node	point	

- Nodes that bound Edges may not be on underlying curves
- Edges in the Loops that trim a Face may not sit on the surface hence the use of pcurves
- * Loops may be geometry free or have associated pcurves (one for each Edge) and the surface where the pcurves reside

See [\\$ESP_ROOT/doc/Concepts.pdf](#) for a pictorial view of EGADS Topology

Node

- Contains a point – $[x, y, z]$
- Member Types: **none**

Edge

- Has a 3D curve (if not DEGENERATE)
- Has a t range (t_{min} to t_{max} , where $t_{min} < t_{max}$)
Note: The positive orientation is going from t_{min} to t_{max}
- Has a Node for t_{min} and for t_{max} – can be the same Node
- Member Types:
 - ONENODE – periodic
 - TWONODE – a normal Edge
 - DEGENERATE – single Node
marks a collapsed u or v on a SURFACE
 t range specifies the limits used for the pcurve (in the Loop)

Loop – without a reference surface

- ① Free standing connected Edges
See page 36 for parsing a non-manifold WireBody
 - ② A list of connected Edges associated with a Plane (which does not require pcurves)
- An ordered collection of Edge objects with associated senses that define the connected Loop
 - Segregates space by maintaining material to the left of the running Loop (or traversed right-handed pointing out of the intended volume)
 - No Edges should be Degenerate
 - Member Types: OPEN or CLOSED (comes back on itself)

Loop – with a reference surface

- ① Collections of Edges (like Loops without a surface) followed by a corresponding collection of pcurves that define the $[u, v]$ trimming on the surface
- Degenerate Edges are required when the $[u, v]$ mapping collapses like at the apex of a cone (note that the pcurve is needed to be fully defined using the Edge's t range)
- An Edge may be found in a Loop twice (with opposite senses) and with different pcurves. For example a closed cylindrical surface at the seam – one pcurve would represent the beginning of the period where the other is the end of the periodic range.
- Types: OPEN or CLOSED (comes back on itself)

Face

- A surface bounded by one or more Loops with associated senses
- Only one outer Loop (sense = SOUTER(1)) and any number of inner Loops (sense = SINNER(-1)). Note that under very rare conditions a Loop may be found in more than 1 Face – in this case the one marked with sense = +/- 2 must be used in a reverse manner.
- All Loops must be CLOSED
- Loop(s) must not contain reference geometry for Planar surfaces
- If the surface is not a Plane then the Loop's reference Object must match that of the Face
- `mtype` is the orientation of the Face based on surface's $U \otimes V$:
 - SFORWARD or SREVERSE when the orientations are opposed

Note that this is coupled with the Loop's orientation (i.e. an outer Loop traverses the Face in a right-handed manner defining the outward direction)

Shell

- A collection of one or more connected Faces that if CLOSED segregates regions of 3-Space
- All Faces must be properly oriented
- Non-manifold Shells can have more than 2 Faces sharing an Edge
- Member Types: OPEN (including non-manifold) or CLOSED
- CLOSED Shells are required for SOLIDBODY Body types

Body

- Container used to aggregate Topology
- *Owns* all the Objects contained within
- Member Types:
 - WIREBODY – contains a single Loop
call EG_getBodyTopos on Edges and compare to the number of Edges in the Loop
if different → non-manifold therefore use the Edges returned from EG_getBodyTopos
 - FACEBODY – contains a single Face – IGES import
 - SHEETBODY – contains one or more Shell(s) which can be either non-manifold or manifold (though usually a manifold Body of this type is promoted to a SOLIDBODY)
 - SOLIDBODY:
 - A manifold collection of one or more CLOSED Shells with associated senses
 - There may be only one outer Shell (sense = SOUTER(1)) and any number of inner Shells (sense = SINNER(-1))
 - Edges (except DEGENERATE) found exactly twice (sense = ± 1)

Topology	BRep define	Effective define	Note
Model			Container for Bodies, EBodies & Tessellations
Body	BODY	EBODY	An EBody is a modification of a Body w/ “E” entities
Shell	SHELL	ESHELL	1 to 1 mapping
Face	FACE	EFACE	EFace consists of 1 or more Faces
Loop	LOOP	ELOOPX	Collection of EEdges, No pcurves
Edge	EDGE	EEDGE	EEdge consists of 1 or more ordered Edges
Node	NODE	n/a	no ENodes, but not all Nodes in the Body are found in the EBody

Virtual Topology & BRep closure

- BRep Topology can inhibit *quality* meshes
 - Spurious Nodes
 - Small Edges that could be coalesced
 - Sliver Faces
- EGADS' *Effective Topology*
 - Automatically removes spurious Nodes (unless the Node has .Keep attribute)
 - Automatically coalesces Edges (unless the Edge has .Keep attribute) to make EEdges
 - Collects Faces explicitly or by attribute
 - uses a global $[u, v]$ mapping driven by an EGADS tessellation
 - Face triangulations must *touch* along at least 1 triangle side
 - EFaces & EEdges contain no geometry, therefore depend on the included BRep Objects
 - Adjusts EFace & EEdge inverse and forward evaluations based on closure at bounds

- *Effective Topology* Objects can maintain their own attributes
- EBody Objects can have their own tessellations.
- *Effective Topology* Objects can NOT be used in construction.
- Nodes that have Degenerate Edges cannot disappear from the EBody. This also means that certain collections of Faces will not be allowed that may remove all Edges supporting that Node.
- EFaces (of more than 1 Face) are always SFORWARD
- The direction of the EEdge is set by the first Edge in the collection. This means that a positive direction is based on the connecting Node to the next Edge, which may have the first Edge traversed in the negative sense.
- The rules for collecting entities in Solid Bodies differ from those of Sheet Bodies where Edges are exposed (only trimming a single Face). In this case an angle criteria is used when making EEdges and removing Nodes.
- A Face may be evaluated throughout the *UVbox* range. This is not true for EFaces containing more than a single Face. An evaluation is only valid based on the original input tessellation.

Discrete representation of an Object

Geometry

- Unconnected discretization of the range of the Object
 - Polyline for curves at constant t increments
 - Regular grid for surfaces at constant increments (isoclines)

Body/EBody Topology

- Connected and trimmed tessellation including:
 - Polyline for Edges/EEdges
 - Triangulation for Faces/EFaces
 - Optional Quadrilateral Patching for Faces/EFaces
- Ownership and Geometric Parameters for Vertices
- Adjustable parameters for side length and curvature (x2)
- Watertight
- Exposed per Face/Edge or Global indexing

Control of the use of Quadrilateral Templates

- Automatic with triangulation scheme
- Attempts to isolate 3 or 4 “sides”
 - Only single Loop/ELoop
 - Faces/EFaces with more than 4 Edges/EEdges are analyzed to see if multiple EDGES can be treated as a single “side”
- Point counts on sides (based on Edge/EEdge Tessellation):
 - TFI if opposites are equal
 - Templates otherwise
- Defeated/modified with Body/EBody or Face/EFace attribute .qParams
 - If ATTRSTRING – turn off quadding templates
 - If ATTRREAL (3 in length):
 - 1 Edge/EEdge matching expressed as the deviation from alignment [default: 0.05]
 - 2 Maximum quad side ratio point count to allow [default: 3.0]
 - 3 Number of smoothing iterations [default: 0.0]

Manual Watertight Quadrilateral Face/EFace Treatment

- Requires Existing Body/EBody Tessellation
- Must be able to Isolate 4 “sides”
 - Only single Loops/ELoops
 - Faces/EFaces with more than 4 Edges/EEdges are analyzed to see if multiple Edges/EEdges can be treated as a single “side”
 - No DEGENERATE Edges/EEdges
- Point counts on sides (based on Edge/EEdgeTessellation):
 - TFI if opposites are equal
 - Templates otherwise
- Can use Edge Tessellation Adjustment Functions when point counts don't allow for Quadding
- See the function EG_makeQuads – page 123.

Body/EBody Watertight Full Quadrilateral Treatment

- Fully automatic & robust
- Method:
 - 1 Starts from an EGADS triangulation of a Body (Tessellation Object)
 - 2 Subdivides all triangle sides so that each triangle becomes 3 quadrilaterals
 - 3 iterate on a regularization scheme:
 - swap/insert/collapse so that the *valence* at each vertex approaches 4 while maintaining a valid tessellation
- Driven by the Edge discretizations, which should start out as double the desired size
- Results in an unstructured tessellation unless the underlying triangulation was derived from TFI
- See the function `EG_quadTess` – page 116.

Models can contain Body, *Effective Topology* and Tessellation Objects, unless they are the output from construction operators. In this case the Model will only contain Body Objects. Models can be created with `EG_makeTopology` (see page 89) and parsed by using `EG_getTopology` (see page 90). These rules apply:

- `nchild` is always the number of Bodies and should be less than or equal to `mtype` (`mtype` can be zero, indicating no ancillary egos).
- You must look at the `oclass` (on the children) of any egos after the Bodies to figure out the kind of object.
- Any Tessellation of EBodies must be listed after the EBody referenced.
- The order of the non-Body children is the same as they were when the Model was created.
- Tessellations and EBodies must be closed when the Model is created.
- Tessellation Objects cannot be reopened once in a Model.
- The Model must contain any Bodies/EBodies referenced by Tessellation Objects and Bodies referenced by EBodies.
- Just like Bodies, Objects in a Model become “owned” by the Model and get deleted when the Model is deleted (and cannot be deleted individually).

TRANSFORM

- Used when copying Objects to change the root position and orientation

REFERENCE

- Allows for the management of Objects that refer to other Objects (so that deletion does not invalidate the information)
- An internal Object and is not usually seen by the EGADS programmer

Parent Child References

- Child Objects used with “make” functions are referenced by the resulting Geometric/Topologic parent Object.

Object Deletion

- Objects are deleted individual with `EG_deleteObject` (all objects are removed with `EG_close`).
- Referenced child Objects can only be deleted after the parent Object is deleted, i.e. in reverse order of the construction.
- Unconnected Geometric & Topologic Objects (i.e. not in a Body) can be deleted *en masse* by invoking `EG_deleteObject` (see page 52) on the Context.

BODY

- When created, all child Objects are copied and stored instead of referenced
- The child Objects can be removed with `EG_deleteObject` in reverse construction order (or *en masse* with `EG_deleteObject` on the Context)

MODEL

- A Body, EBody or Tessellation Object can be included in only one MODEL (you will get a “reference error” if violated)
- Because Tessellation and EBody Objects reference Body Objects, the Body may need to be copied before creating Tessellations and EBodies if any are to be included in a Model
- Deleting a Model also deletes all child Objects contained within the Model

The following pages provide a reference for the EGADS API. Each block describes the function *signature* first using C/C++, then Fortran, then the **Python call in violet** (when using pyEGADS) and last the **Julia call in green** (when using jlEGADS). For C/C++/Fortran:

- Function names begin with “EG_” (C/C++)
- Function names begin with “IG_” for the FORTRAN bindings
- Functions almost always return an integer *error code*
- *Object-based* – procedural, usually with the first argument an **ego**
- Signatures usually have the inputs first, then output argument(s)
- Some outputs may be pointers to lists of *things*
 - EG_free (page 63) needs to be used when marked as “freeable”
- **El** indicates an EGADSlite, **ET** an *Effective Topology* function, **dot** indicates sensitivity functions exist

See `$ESP_ROOT/include/egads.h` & `egads_dot.h` for a complete listing of the functions.
See `$ESP_ROOT/include/egadsErrors.h` for a list of the return code **defines**.

The Python EGADS API is built on `ctypes` and mirrors the C/C++ API. Methods have similar names and arguments, which are ordered consistently when possible (optional arguments are placed last).

C-arrays with strides are `lists` of `tuples`.

Import statement: `from pyEGADS import egads`

Main API classes: `egads.Context` `egads.ego` `egads.c_ego`

- `c_ego` is a `ctypes` struct for C function arguments of C `ego` type
- Python classes `Context` and `ego` wrap a `c_ego` and implement EGADS API
 - The wrapped `c_ego` is automatically deleted when a Python class is created from an `egads` method
- Python classes can be created using a `c_ego` generated outside of `egads` using the `egads.c_to_py(c_obj, deleteObject=False)` function
 - `deleteObject` indicates if the `c_ego` should be automatically deleted
- The `c_ego` is retrieved from with `object.py_to_c(takeOwnership=False)`
 - `takeOwnership=True` indicates the returned `c_ego` will no longer be automatically deleted

The Julia EGADS API mirrors the C/C++ API.

Methods have same names and similar arguments (ordered), **except**

- Optional arguments (declared after “;”) use keywords
- Arguments indicating array size are excluded

1D Arrays are indicated as `[]` and 2D Arrays as `[][]`

- Functions with argument `[]([])` take 1DArray (flattened) or 2DArray
- Functions with argument `DataType([])` take single value or 1DArray

Import statement: `import egads`

Usage: `egads.function_name()`

Main API structures: `egads.Ctxt`, `egads.Ego`

- In this document, the prefix `egads.` is omitted

Context and **Ego** are **Julia structures** wrapping a C **ego** type

- They can be created using a C **ego** generated outside of **egads** calling
`egads.Context(obj=ego)` `egads.Ego(ego,ctxt=Context)`
- The wrapped **ego** is automatically deleted using **Julia finalizers**

Functions modifying input values use signature `! eg., egads.function!()`

Functions **don't** return **icode** status. Rather, an internal error is raised

Get revision

E1

```
EG_revision(int *imajor, int *iminor, const char **OCCrev);  
call IG_revision(I*4 imajor, I*4 iminor, C** OCCrev)  
imajor, iminor, OCCrev = egads.revision()  
imajor, iminor, OCCrev = revision()
```

imajor the returned major revision

iminor the returned minor revision number

OCCrev the returned revision of OpenCASCADE in use

Returns the version information for both EGADS and OpenCASCADE.

Open EGADS

E1

```
icode = EG_open(ego *context);  
icode = IG_open(I*8 context)  
context = egads.Context()  
context = Context()
```

context the returned Context Object

icode the integer return code

Opens and returns a Context object. This is required for the use of all EGADS (except for the above).

Close a Context

E1

```
icode = EG_close(ego context);  
icode = IG_close(I*8 context)  
    del context
```

context the Context Object to close

icode the integer return code

Cleans up and closes the Context.

Delete Object

E1

```
icode = EG_deleteObject(ego object);  
icode = IG_deleteObject(I*8 object)  
    del object
```

object the Object to delete

icode the integer return code

Deletes an Object (if possible). A positive return indicates that the Object is still referenced by this number of other Objects and has not been removed from the Context. If the Object is the Context then all Geometry/Topology Objects in the Context are deleted except those attached to Body/EBody or Model Objects. You cannot delete lesser *Effective Topology* Objects than an EBody.

E1 Note: Only Objects created in an EGADSlite session may be deleted.

Read Geometric data from a File

```

icode = EG_loadModel(ego context, int bitFlag, const char *name,
                    ego *model);
icode = IG_loadModel(I*8 context, I*4 bitFlag, C**          name,
                    I*8 model)

model = context.loadModel(name, bitFlag=0)
model = loadModel(context::Context, bitFlag::Int, name::string)

```

context the Context Object to receive the geometry

bitFlag Options (additive):

- 1 Don't split closed and periodic entities
- 2 Split to maintain at least C^1 in BSPLINES
- 4 Don't maintain Units on STEP/IGES read (always millimeters)
- 8 Try to merge Edges and Faces (with same geometry)
- 16 Load unattached Edges as WireBodies (stp/step & igs/iges)

name path of file to load (with extension – case insensitive):

- igs/iges IGES file
- stp/step STEP file
- brep native OpenCASCADE file
- egads native file format with persistent Attributes (splits ignored)

model the returned Model Object that was read

icode the integer return code

Loads and returns a Model Object from disk and puts it in the Context.

See page 55 for more information on STEP & IGES import/export

Writes the Model to a File

```
icode = EG_saveModel(const ego object, const char *name);  
icode = IG_saveModel(I*8 object, C** name)  
    object.saveModel(name, overwrite=False)  
    saveModel!(object::Ego, name::string; overwrite::Bool)
```

object the Model Object to write

name path of file to write, type based on extension (case insensitive):

igs/iges IGES file

stp/step STEP file

brep a native OpenCASCADE file

egads a native file format with persistent Attributes and the ability to write
EBody and Tessellation data

icode the integer return code

Writes the BReps (with optional Tessellation and EBody Objects) contained in the Model to disk. Only writes BRep data for anything but EGADS output. Will not overwrite an existing file of the same name unless `overwrite=True`.

Notes:

- 1 **object** can be a single Body for convenience
- 2 See page 55 for more information on STEP & IGES import/export

Length Units

EGADS is unitless but the file standards are not. To deal with this the attribute “.lengthUnits” (which is set to a string) is used:

- On import (EG_loadModel):
 - Any Body loaded has “.lengthUnits” set to the import unit designation
- On export (EG_saveModel):
 - If “.lengthUnits” is found on the Model Object this unit string is used
 - Otherwise all Bodies are examined for “.lengthUnits” and if any is found it is used
 - If none are found, then “millimeters” is used
 - If there is any inconsistency when examining multiple Bodies – “millimeters” is used

Attributes

STEP/IGES can only mark Topology with “Name”, “Layer” and “Color”. In EGADS, the “Name” string attribute is handled on all topological objects, “Color” on Faces and Edges, during import/export.

“Color” may be one of “red”, “lred”, “green”, “lgreen”, “blue”, “lblue”, “yellow”, “magenta”, “cyan”, “white”, “black”, or three $RGB \in [0, 1]$ reals.

Notes:

- STEP supports Body attributes “ColorFace” and “ColorEdge” for setting Body defaults.
- STEP WireBodies do not support Edge “Color” (use Body “ColorEdge”) or Node “Name”
- Edge attributes do not export to IGES when the Edge is associated with two or more Faces.
- IGES does not support “Name” on Nodes

Update Thread ID in Context

```
icode = EG_updateThread(ego context);  
icode = IG_updateThread(I*8 context)  
context.updateThread()  
updateThread!(context::Context)
```

context the Context Object to update

icode the integer return code

Resets the Context's owning thread ID to the thread calling this function.

Make a Transform

```
icode = EG_makeTransform(ego context, double *mat, ego *xform);  
icode = IG_makeTransform(I*8 context, R*8 mat, I*8 xform)  
xform = context.makeTransform(mat)  
xform = makeTransform(context::Context, mat::Float[][])
```

context the Context

mat the 12 values of the translation/rotation matrix

xform the returned Transformation Object

icode the integer return code

Makes a Transformation Object from a translation/rotation matrix. The rotation portion [3][3] must be an orthonormal matrix with a single scale.

Get matrix from Transform Object

```
icode = EG_getTransform(const ego xform, double *mat);  
icode = IG_getTransform(I*8 xform, R*8 mat)  
    mat = xform.getTransform()  
    mat = getTransform(xform::Ego)
```

xform the Transformation Object

mat the filled 12 values of the translation/rotation matrix

icode the integer return code

Returns the transformation information. This appears like is a column-major matrix that is 4 columns by 3 rows and could be thought of as [3][4] in C/C++ (though is flat) and in Fortran dimensioned as (4, 3).

Copy and flip the orientation of an Object

```
icode = EG_flipObject(const ego object, ego *newObject);  
icode = IG_flipObject(I*8 object, I*8 newObject)  
newObject = object.flipObject()  
newObject = flipObject(object::Ego)
```

object the Object to flip

newObject The resultant new Object

icode the integer return code

Creates a new EGADS Object by copying and reversing the input object. Can be Geometry (flip the parameterization) or Topology (reverse the sense). Not for Node, Edge, Body or Model. Surfaces reverse only the *u* parameter.

Copy and optionally Transform an Object

```
icode = EG_copyObject(const ego object, void *other, ego *newObj);  
icode = IG_copyObject(I*8 object, I*8 other, I*8 newObj)  
newObj = object.copy(other, other=None)  
newObj = copyObject(object::Ego; other::Ego)
```

object the Object to copy

other a Transformation Object, a Body Object, **NULL** for a strict copy, or a vector of **doubles**

newObj The resultant new Object

icode the integer return code

Creates a new EGADS Object by copying and optionally transforming the input object. A Tessellation or PCurve Object cannot be transformed. For a Tessellation Object, **other** can be a vector of displacements that is 3 times the number of vertices of **doubles** in length to *morph* the tessellation. Also, if **object** is a Tessellation Object or an EBody Object and **other** is a Body Object, the existing Object is copied but associated with the Body specified (not the original referenced object). Note that **other** is not checked if it is compatible with the original referenced Body.

If **other** is a Context, then **object** is copied to this target Context. This is useful in multithreaded settings.

Use `EG_copyGeometry_dot` when requiring sensitivities during construction.

Copy an Object to the specified Context

```
icode = EG_contextCopy(ego context, const ego object, ego *newObj);  
icode = IG_contextCopy(I*8 context, I*8 object, I*8 newObj)  
newObj = context.contextCopy(object)  
newObj = contextCopy(context::Context; object::Ego)
```

context the Context to put the copy (must be a Body for copying a Tessellation Object)

object the Object to copy – can be either topology or geometry (but not a PCurve)
Tessellation Objects may be copied but **context** must be the corresponding Body in the appropriate Context (usually copied before copying the tessellation)
Note: **object** must not be in the Context

newObj The resultant new Object

icode the integer return code

This is useful in multithreaded settings when you wish to copy an **object** that exists in a different Context/thread. Use `EG_copyObject` (page 58) when copying from the **object**'s context/thread to the context specified by **other**.

Get information about an Object

ET, E1

```
icode = EG_getInfo(const ego object, int *oclass, int *mtype,
                  ego *topObj, ego *prev, ego *next);
icode = IG_getInfo(I*8 object, I*4 oclass, I*4 mtype,
                  I*8 topObj, I*8 prev, I*8 next);
oclass, mtype, topObj, prev, next = object.getInfo()
oclass, mtype, topObj, prev, next = getInfo(object::{Ego,Context})
```

object the queried Object

oclass the returned Object Class

mtype the returned Member Type

topObj the returned the top level Body/EBody/Model that *owns* **object** or Context

prev the returned previous Object in the threaded list (**NULL** at Context)

next the returned next Object in the threaded list (**NULL** is the end of the list)

icode the integer return code

Queries Object level information. **mtype**'s meanings depend on the returned **oclass** value.

The arguments **topObj**, **prev** and/or **next** can be **NULL** if you do not need these **egos**.

Get the Context

```
icode = EG_getContext(ego object, ego *context);  
icode = IG_getContext(I*8 object, I*8 *context)  
context = object.context  
context = object.ctx
```

object the queried Object

context the returned owning Context

icode the integer return code

Returns the Context given an object. The context is a property in Python.

Set the Verbosity Level

E1

```
icode = EG_setOutLevel(ego context, int outLevel);  
icode = IG_setOutLevel(I*8 context, I*4 outLevel)  
context.setOutLevel(outLevel)  
setOutLevel(context::Context, outLevel::Int)
```

context the Context

outLevel the verbosity level: 0-silent to 3-debug

icode the integer return code

Sets the EGADS verbosity level, the default is 1. Success returns the old outLevel.

Writes a Model to a stream

```
icode = EG_exportModel(ego model, size_t *nbyte, char **stream);
icode = IG_exportModel(I*8 model, I*8 nbyte, CPTR stream)
stream = model.exportModel()
stream = exportModel(model::Ego)
```

model the Model Object to export

nbyte the returned number of bytes in **stream**

stream the returned pointer to the byte-stream (freeable)

Create a stream of data serializing the objects in the Model (including EBodies and Tessellations).

Loads a Model from a stream

E1 only

```
icode = EG_importModel(ego context, const size_t *nbyte,
                        const char **stream, ego *model);
icode = IG_importModel(I*8 context, I*8 nbyte,
                        CPTR stream, I*8 model)
model = importModel(stream::UInt[])
```

context the Context Object to place the import

nbyte the number of bytes in **stream**

stream the pointer to the byte-stream

model the returned Model Object

Deserialize the stream into the objects (Bodies/EBodies/Tessellations) that make up the returned Model.

Memory Functions

E1

```
EG_free(void *ptr);  
call IG_free(CPTR ptr)
```

```
void *ptr = EG_alloc(size_t nbytes);  
icode = IG_alloc(I*4      nbytes, CPTR ptr)
```

```
void *ptr = EG_calloc(size_t nele, size_t size);  
icode = IG_calloc(I*4      nele, I*4      size, CPTR ptr)
```

```
void *ptr = EG_reall(void *pointer, size_t nbytes);  
icode = IG_reall(CPTR pointer, I*4      nbytes, CPTR ptr)
```

```
char *str = EG_strdup(const char *string);
```

These functions need to be used instead of the C/C++ variants for persistent memory due to the need to allocate/free from the same DLL under Windows.

None of this is necessary within pyEGADS except for one exception – `egads.free(ptr)` releases memory returned from a ctypes interface

Add an Attribute to an Object

```
icode = EG_attributeAdd(ego object, const char *name, int type,
                        int len, const int *ints, const double *reals,
                        const char *string);
icode = IG_attributeAdd(I*8 object, C**          name, I*4 type,
                        I*4 len, I*4          ints, R*8          reals,
                        C**          string)
object.attributeAdd(name, attrVal)
attributeAdd!(object::Ego, name::String, attrVal::{Number[],String})
```

object the Object to attribute
name the name of the attribute
type the attribute type: ATTRINT, ATTRREAL, ATTRSTRING, ATTRCSYS[†] or ATTRPTR
len the number of integers or reals (ignored for strings and pointers)
ints the integers for ATTRINT
reals the floating-point data for ATTRREAL or ATTRCSYS
string the character string pointer for ATTRSTRING or ATTRPTR types
icode the integer return code

Notes: Only the one appropriate **attribute** value (of **ints**, **reals** or **string**) is required.

[†] Use `-attrVal = egads.csystem(reals)` to make a CSYS value.

Delete an Attribute from an Object

```
icode = EG_attributeDel(ego object, const char *name);  
icode = IG_attributeDel(I*8 object, C**      name)  
    object.attributeDel(name)  
    attributeDel!(object::Ego; name::String)
```

object the Object

name the name of the attribute to delete

icode the integer return code

Deletes an attribute from the Object. If the name is **NULL** (or no argument) then all attributes are removed from this Object.

The number of Object Attributes

E1

```
icode = EG_attributeNum(ego object, int *nAttr);  
icode = IG_attributeNum(I*8 object, I*4  nAttr)  
nAttr = object.attributeNum()  
nAttr = attributeNum(object::Ego)
```

object the Object

nAttr the returned number of attributes attached to the Object

icode the integer return code

Returns the number of attributes found with this object.

Return an Attribute on an Object

E1

```

icode = EG_attributeRet(ego object, const char *name, int *type,
                      int *len, const int **ints,
                      const double **reals, const char **string);
icode = IG_attributeRet(I*8 object, C**          name, I*4 type,
                      I*4 len, I*4          ints,
                      R*8          reals, C**          string)

attrVal = object.attributeRet(name)
attrVal = attributeRet(object::Ego, name::String)

```

object the Object to query

name the name to query

type the type: ATTRINT, ATTRREAL, ATTRSTRING, ATTRCSYS or ATTRPTR

len the returned number of integers or reals

ints the returned pointer to integers for ATTRINT

reals the returned pointer to floating-point data for ATTRREAL or ATTRCSYS

string the returned pointer to a character string for ATTRSTRING or ATTRPTR types

icode the integer return code

Notes: Only the appropriate **attribute** value (of **ints**, **reals** or **string**) is returned.

Care must be taken with the string variable in Fortran not to overstep the declared length.

The CSys (12 reals) is returned in **reals** after the **len** values.

Get an Attribute on an Object

E1

```

icode = EG_attributeGet(ego object, int index, const char **name,
                      int *type, int *len, const int **ints,
                      const double **reals, const char **string);
icode = IG_attributeGet(I*8 object, I*4 index, C**      name,
                      I*4 type, I*4 len, I*4      ints,
                      R*8      reals, C**      string)

name, attrVal = object.attributeGet(index)
name, attrVal = attributeGet(index::Int)

```

object the Object to query

index the index (1 to **nAttr** from EG_attributeNum)

name the returned name

type the type: ATTRINT, ATTRREAL, ATTRSTRING, ATTRCSYS or ATTRPTR

len the returned number of integers or reals

ints the returned pointer to integers for ATTRINT

reals the returned pointer to floating-point data for ATTRREAL or ATTRCSYS

string the returned pointer to a character string for ATTRSTRING or ATTRPTR types

icode the integer return code

Notes: Only the appropriate **attribute** value (of **ints**, **reals** or **string**) is returned.

Care must be taken with the string variable in Fortran not to overstep the declared length.

The CSys (12 reals) is returned in **reals** after the **len** values.

Copy the Attributes from an Object to another

```
icode = EG_attributeDup(ego src, ego dst);  
icode = IG_attributeDup(I*8 src, I*8 dst)  
    dst.attributeDup(src)  
    attributeDup!(src::Ego, dst::Ego)
```

src the source Object

dst the Object to receive **src**'s attributes

icode the integer return code

Deletes an attribute from the destination Object and then copies the source's attributes to the destination. ATTRPTR attributes copy the pointer, other types allocate new data and copy the contents of the source.

Change Attribute Mode

```
icode = EG_setFullAttrs(ego context, int attrFlag);  
icode = IG_setFullAttrs(I*8 context, I*4 attrFlag)  
    context.setFullAttrs(attrFlag)  
    setFullAttrs!(context::Context, attrFlag::Int)
```

context the Context Object

attrFlag the mode flag: 0 – the default scheme, 1 – full attribution mode

icode the integer return code

Sets the attribution mode for the Context.

- `EG_attributeAdd`'s functionality is the same in both modes. It overwrites an existing attribute with the same name. The name can have the sequence number (when overwriting, not adding). It is an error if the name with sequence does not exist. If the name of the attribute is the “root” name of an existing sequence, this raises an error. Use `EG_attributeAddSeq` to add additional attributes with the same root name to a sequence.
- `EG_attributeDel`, given a name with a sequence number, only deletes that attribute. Note: this will cause resequencing of the attributes such that there is no gap in the attribute sequence numbering. If only one attribute remains in the sequence, the sequence number is removed. Given a name without a sequence number, it will delete all attributes with that root name.
- `EG_attributeNum` returns the number of all attributes including those with sequence numbers.
- `EG_attributeGet` functionality is equivalent in either mode.
- `EG_attributeRet` accepts names with sequence numbers. An error is raised if the input name does not have a sequence number and there are multiple attributes in the sequence. See `EG_attributeRetSeq` on page 72.
- `EG_attributeDup`'s functionality changes depending on the mode. With full attribution it follows the merge rules seen on page 15. That is, if the destination object already has the attributes they will not be overwritten. If you want to overwrite the existing attributes in full mode, invoke `EG_attributeDel` with **NULL** and then call `EG_attributeDup`.

Add an Attribute to an Object

```
icode = EG_attributeAddSeq(ego object, const char *name, int type,
                          int len, const int *ints,
                          const double *reals, const char *string);
icode = IG_attributeAddSeq(I*8 object, C**          name, I*4 type,
                          I*4 len, I*4          ints,
                          R*8          reals, C**          string)
object.attributeAddSeq(name, attrVal)
attributeAddSeq!(obj::Ego, name::String, attrVal::{Number[],String})
```

- object** the Object to attribute
- name** the name of the attribute
- type** the attribute type: ATTRINT, ATTRREAL, ATTRSTRING, ATTRCSYS[†] or ATTRPTR
- len** the number of integers or reals (ignored for strings and pointers)
- ints** the integers for ATTRINT
- reals** the floating-point data for ATTRREAL or ATTRCSYS
- string** the character string pointer for ATTRSTRING or ATTRPTR types
- icode** the integer return code or sequence number (0, 2 and on)

Notes: Only the appropriate **attribute** value (of **ints**, **reals** or **string**) is required.

[†] Use `-attrVal = egads.csystem(reals)` to make a CSYS value.

If there are no attributes with this name on the object this acts just like `EG_attributeAdd`.

The number of Sequenced Attributes

E1

```
icode = EG_attributeNumSeq(ego object, const char *name, int *nSeq);  
icode = IG_attributeNumSeq(I*8 object, C**          name, I*4  nSeq)  
    nSeq = object.attributeNumSeq(name)  
    nSeq = attributeNumSeq(object::Ego, name::String)
```

object the Object

name the name of the attribute

nSeq the returned number of sequence attributes with the name
0 for no sequencing, 2 or more for the number of attributes in the root name sequence

icode the integer return code

Returns the number of named sequenced attributes found on this object.

Return a Sequenced Attribute on an Object

E1

```

icode = EG_attributeRetSeq(ego object, const char *name, int index,
                           int *type, int *len, const int **ints,
                           const double **reals, const char **string);
icode = IG_attributeRetSeq(I*8 object, C**      name, I*4 index,
                           I*4 type, I*4 len, I*4      ints,
                           R*8      reals, C**      string)

attrVal = object.attributeRetSeq(name, index)
attrVal = attributeRetSeq(object::Ego, name::String, index::Int)

```

object the Object to query

name the “root” name to query

index the sequence number (1 to nSeq)

type the type: ATTRINT, ATTRREAL, ATTRSTRING, ATTRCSYS or ATTRPTR

len the returned number of integers or reals

ints the returned pointer to integers for ATTRINT

reals the returned pointer to floating-point data for ATTRREAL or ATTRCSYS

string the returned pointer to a character string for ATTRSTRING or ATTRPTR types

icode the integer return code

Notes: Only the appropriate **attribute** value (of **ints**, **reals** or **string**) is returned.

Care must be taken with the string variable in Fortran not to overstep the declared length.

The CSys (12 reals) is returned in **reals** after the **len** values.

Create a Geometry Object

dot

```

icode = EG_makeGeometry(ego context, int oclass, int mtype, ego rGeom,
                        const int *ints, const double *reals,
                        ego *nGeom);

icode = IG_makeGeometry(I*8 context, I*4 oclass, I*4 mtype, I*8 rGeom,
                        I*4      ints, R*8      reals,
                        I*8   nGeom)

nGeom = context.makeGeometry(oclass, mtype, reals, ints=None,
                             geom=None)

nGeom = makeGeometry(ctxt::Ctxt, oclass::Int, mtype::Int, rGeom::Ego,
                     reals::Float[] ([]), ints::Int[])

```

context the Context Object

oclass the Object Class: PCURVE, CURVE or SURFACE

mtype the Member Type (depends on **oclass**)

rGeom the reference Geometry Object (if none use **NULL**)

ints the integer information (if none use **NULL**)

reals the real data used to construct the geometry

nGeom the returned pointer to the new Geometry Object

icode the integer return code

Notes: **ints** is required for either **mtype** = BEZIER or BSPLINE.

See pages 16-29 for a complete listing of **oclass/mtype** data requirements.

Query a Geometry Object

dot, El

```

icode = EG_getGeometry(ego object, int *oclass, int *mtype,
                       ego *rGeom, int **ints, double **reals);
icode = IG_getGeometry(I*8 object, I*4 oclass, I*4 mtype,
                       I*8 rGeom, I*4 ints, R*8 reals)

oclass, mtype, reals, ints, rGeom = object.getGeometry()
oclass, mtype, reals, ints, rGeom = getGeometry(object::Ego)

```

object the Geometry Object

oclass the returned Object Class: PCURVE, CURVE or SURFACE

mtype the returned Member Type (depends on **oclass**)

rGeom the returned reference Geometry Object (**NULL** if none)

ints the returned pointer to integer information (**NULL** if none) (*freeable*)

reals the returned pointer to real data used to describe the geometry (*freeable*)

icode the integer return code

Notes: **ints** is returned for either **mtype** = BEZIER or BSPLINE.

See pages 16-29 for a complete listing of **oclass/mtype** data information.

Create a Surface by *skinning* Curves

```
icode = EG_skinning(int nCurve, ego *curves, int degree,  
                   ego *bspline);  
icode = IG_skinning(I*4 nCurve, I*8 curves, I*4 degree,  
                   I*8 bspline)  
bspline = egads.skinning(curves, degree=3)  
bspline = skinning(curves::Ego[], degree::Int)
```

nCurve the number of BSpline curves to *skin*

curves a pointer to a vector of **egos** containing non-periodic, non-rational BSPLINE curves properly positioned and ordered

degree degree of the BSpline used in the *skinning* direction

bspline the returned pointer to the new BSpline Surface Object

icode the integer return code

This function produces a BSpline Surface that is not fit or approximated in any way, and is true to the input curves.

Create an Object by Fitting data to a BSpline

dot

```

icode = EG_approximate(ego context, int mDeg, double tol,
                      const int *sizr, const double *xyz, ego *bspl);
icode = IG_approximate(I*8 context, I*4 mDeg, R*8 tol,
                      I*4      sizr, R*8      xyz, I*8  bspl)

bspl = context.approximate(sizr, xyz, mDeg=0, tol=1.e-8)
bspl = approximate(context::Ctxt, sizr::Int[], xyz::Float[][];
                  mDeg::Int, tol::Float)

```

context the Context Object

mDeg[†] the maximum degree used by OpenCASCADE [3-8], or cubic by EGADS [-3-2]:

-1/0 – fixes the bounds and uses natural end conditions

-2/1 – fixes the bounds and maintains the slope input at the bounds

-3/2 – fixes the bounds & quadratically maintains the slope at 2nd order

tol is the tolerance to use for the BSpline approximation procedure,
zero for a SURFACE fit (OpenCASCADE)

sizr a vector of 2 integers that specifies the size and dimensionality of the data. If the second is zero, then a CURVE is fit and the first integer is the length of the number of [x, y, z] triads. If the second integer is nonzero, then the input data reflects a 2D map.

xyz the data to fit (3 times the number of points in length)

bspl the returned pointer to the new BSPLINE Geometry Object

icode the integer return code

[†] Notes: negative indicates periodic where the first point must be identical to the last; for SURFACES the periodicity may only be in U; periodic CURVES must be -1 only; this forces equally spaced knots; the result is C2 but not a *periodic* BSPLINE.

Create an Object by Fitting a BSpline to triangles

```
icode = EG_fitTriangles(ego context, int len, double *xyzs, int ntris,
                        const int *tris, const int *tric, double tol,
                        ego *bspline);
icode = IG_fitTriangles(I*8 context, I*4 len, R*8 xyzs, I*4 ntris,
                        I*4 tris, I*4 tric, R*8 tol,
                        I*8 bspline)

bspline = context.fitTriangles(xyzs, tris, tric=None, tol=1e-7)
bspline = fitTriangles(ctxt::Ctxt, xyzs::Float[]([]), tris::Int[]([]);
                      tric::Int[], tol::Float)
```

context the Context Object

len the number of vertices in the triangulation

xyzs the data to fit (3 times **len** in length)

ntris the number of triangles

tris the pointer to triangle indices (1 bias) (3 times **ntris** in length)

tric the pointer to neighbor triangle indices (1 bias) – 0 or (-) at bounds
NULL – will compute (3 times **ntris** in length, if not **NULL**)

tol the is the tolerance to use for the BSpline approximation procedure

bspline the returned pointer to the new Geometry Object

icode the integer return code

Computes and returns the resultant object created by approximating the triangulation by a BSpline surface.

Insert additional Knots into a BSpline

```

icode = EG_addKnots(ego bspline,
                    int minDegU, int nU, const double *Us,
                    int minDegV, int nV, const double *Vs, ego *nbspl);
icode = IG_addKnots(I*8 bspline,
                    I*4 minDegU, I*4 nU, R*8          Us,
                    I*4 minDegV, I*4 nV, R*8          Vs, I*8  nbspl)

nbspl = bspline.addKnots(minDegU, Us, minDegV, Vs)
nbspl = addKnots(bspline::Ego, minDegU::Int, Us::Float[],
                 minDegV::Int, Vs::Float[])

```

bspline the BSpline PCurve, Curve or Surface Object

minDegU the minimum Udegree in the resulting BSpline (Degree for PCurve/Curve)

nU the number of U Knots to insert (Knots for PCurve/Curve)

Us the UKnot values to insert (may be repeated) (**nU** in length) (Knots for PCurve/Curve)

minDegV the minimum Vdegree in the resulting BSpline (Ignored for PCurve/Curve)

nV the number of V Knots to insert (Ignored for PCurve/Curve)

Vs the VKnot values to insert (may be repeated) (**nV** in length) (Ignored for PCurve/Curve)

nbspl the returned pointer to the new BSpline Geometry Object

icode the integer return code

The shape of resulting BSpline geometry is unchanged.

Create a CURVE by taking an isocline of a SURFACE

```
icode = EG_isoCline(ego surface, int iUV, double value, ego *curve)
icode = IG_isoCline(I*8 surface, I*4 iUV, R*8 value, I*8 curve)
curve = surface.isoCline(iUV, value)
curve = isoCline(surface::Ego, iUV::Int, value::Float)
```

surface the Surface Object

iUV the type of isocline: UIISO (0) constant U – or – VISO (1) constant V

value the value used for the isocline

curve pointer to the returned isocline curve

icode the integer return code

Computes from the input surface and returns the isocline curve.

Check if PCURVE is an isocline

```
icode = EG_isIsoPCure(ego pcurve, int *iUV, double *value, int *fwd)
icode = IG_isIsoPCure(I*8 pcurve, I*4 iUV, R*8 value, I*4 fwd)
isiso, iso, value, fwd = pcurve.isIsoPCure()
isiso, iso, value, fwd = isIsoPCure(pcurve::Ego)
```

pcurve the PCurve Object

iUV type of isocline (may be NULL): UIISO (0) constant U – or – VISO (1) constant V

value the value of the isocline (may be NULL)

fwd direction of the PCurve (SFORWARD (1) - Forward, SREVERSE (-1) - Reversed)

icode the integer return code (EGADS_SUCCES if pcurve is an iso, EGADS_NOTFOUND otherwise)

Returns the range and periodicity

dot, *ET*, E1

```
icode = EG_getRange(ego object, double *range, int *periodic);
icode = IG_getRange(I*8 object, R*8      range, I*4  periodic)
range, periodic = object.getRange()
range, periodic = getRange(object::Ego)
```

- object** the input Object (PCURVE, CURVE, EDGE, EEDGE, SURFACE, FACE or EFACE)
range PCURVE, CURVE, EDGE, EEDGE – 2 vales are filled: t_{start} and t_{end}
 SURFACE, FACE, EFACE – 4 values are filled: u_{min} , u_{max} , v_{min} and v_{max}
periodic 0 for non-periodic, 1 for periodic in t or u , 2 for periodic in v (or-able)
icode the integer return code

Compute the arc-length of an Object

ET, E1

```
icode = EG_arcLength(ego object, double t1, double t2, double *alen);
icode = IG_arcLength(I*8 object, R*8      t1, R*8      t2, R*8      alen)
alen = object.arcLength(t1, t2)
alen = arcLength(object::Ego, t1::Float, t2::Float)
```

- object** the input Object (PCURVE, CURVE or EDGE)
t1 The starting t value
t2 The end t value
alen the returned resultant arc-length
icode the integer return code

Evaluate on the Object

dot, *ET*, E1

```
icode = EG_evaluate(ego object, double *params, double *result);
icode = IG_evaluate(I*8 object, R*8 params, R*8 result)
result = object.evaluate(params)
result = evaluate(object::Ego, params::Float[])
```

object the input Object

params NODE – ignored (can be **NULL**); PCURVE, CURVE, EDGE, EEDGE – the t value
SURFACE, FACE, EFACE – u then v

result the filled returned position, 1st and 2nd derivatives:

length \Rightarrow	Node – 3	PCurve – 6	Edge / EEdge Curve – 9	Face / EFace Surface – 18
Position	$[x, y, z]$	$[u, v]$	$[x, y, z]$	$[x, y, z]$
1 st	–	$[du, dv]$	$[dx, dy, dz]$	$[dx_u, dy_u, dz_u]$ $[dx_v, dy_v, dz_v]$
2 nd	–	$[du^2, dv^2]$	$[dx^2, dy^2, dz^2]$	$[dx_u^2, dy_u^2, dz_u^2]$ $[dx_{uv}, dy_{uv}, dz_{uv}]$ $[dx_v^2, dy_v^2, dz_v^2]$

icode the integer return code – evaluation on EFace may return EGADS_EXTRAPOL

Note: You cannot evaluate a DEGENERATE Edge/EEdge.

Inverse evaluation on the Object

ET, E1

```

icode = EG_invEvaluate(ego object, double *pos, double *params,
                      double *result);
icode = IG_invEvaluate(I*8 object, R*8      pos, R*8      params,
                      R*8      result)
params, result = object.invEvaluate(pos)
params, result = invEvaluate(object::Ego, pos::Float[])

```

object the input Object

pos is $[u, v]$ for a PCURVE and $[x, y, z]$ for all others

params the returned parameter(s) found for the nearest position on the Object:
 for PCURVE, CURVE, EDGE or EEDGE the one value is t
 for SURFACE, FACE or EFACE the 2 values are u then v

result the closest position found is returned:
 $[u, v]$ for a PCURVE (len = 2)
 $[x, y, z]$ for all others (len = 3)

icode the integer return code

Note: When using this with a Face the timing is significantly slower than making the call with the Face's reference surface (due to the clipping). If you don't need this limiting call EG_invEvaluate with the underlying Surface Object.

Returns the curvature information on the Object *ET, E1*

```
icode = EG_curvature(ego object, double *params, double *result);
icode = IG_curvature(I*8 object, R*8      params, R*8      result)
result = object.curvature(params)
curvature, direction = curvature(object::Ego, params::Float([]))
```

object the input Object

params parameter(s) used to compute on the Object:
 PCURVE, CURVE, EDGE, EEDGE – the t value
 SURFACE, FACE, EFACE – u then v

result the filled returned curvature information:

length \Rightarrow	PCurve – 3	Edge / EEdge Curve – 4	Face / EFace Surface – 8
Curvature	Curvature	Curvature	Curvature1
Direction	$[dir_u, dir_v]$	$[dir_x, dir_y, dir_z]$	$[dir1_x, dir1_y, dir1_z]$
Direction			Curvature2 $[dir2_x, dir2_y, dir2_z]$

icode the integer return code

Note: You cannot get curvature on a DEGENERATE Edge.

Returns other Curve that matches the input Curve

```
icode = EG_otherCurve(ego object, ego curve, double tol, ego *ocurve);  
icode = IG_otherCurve(I*8 object, I*8 curve, R*8 tol, I*8 ocurve)  
ocurve = object.otherCurve(curve)  
ocurve = otherCurve(object::Ego, curve::Ego; tol::Float)
```

- object** the input Object (SURFACE or FACE)
- curve** the input PCurve or Curve/Edge Object
- tol** is the tolerance to use when fitting the output curve
- ocurve** the returned approximated resultant Curve or PCurve Object
- icode** the integer return code

Produces the PCurve from the Curve/Edge or *vice versa*.

Do the Objects represent the same Geometry?

```
icode = EG_isSame(const ego object1, const ego object2);  
icode = IG_isSame(I*8 object1, I*8 object2)  
bool = object1.isSame(object2)  
bool = isSame(object1::Ego, object2::Ego)
```

- object1** the first input Object (NODE, CURVE, EDGE, SURFACE or FACE)
- object2** the second input Object (to make the comparison)
- icode** the integer return code (same is EGADS_SUCCESS, not same is EGADS_OUTSIDE)

Concatenates 2 BSpline curves to make another

```
icode = EG_mergeBSplineCurves(ego curve1, ego curve2, ego *bspline);
icode = IG_mergeBSplineCurves(I*8 curve1, I*8 curve2, I*8 bspline)
bspline = curve1.mergeBSplineCurves(curve2)
bspline = mergeBSplineCurves(curve1::Ego, curve2::Ego)
```

curve1 the first input BSpline CURVE Object

curve2 the second input BSpline CURVE Object

bspline pointer to the returned BSpline CURVE Object

icode the integer return code

The starting and ending control points are matched and used to mate the curves. The direction of the result is fixed by **curve1**. The t range is the sum of the 2 input CURVE ranges scaled by arcLength.

Converts geometry to BSPLINE mt type

```
icode = EG_convertToBSpline(ego object, ego *bspline);
icode = IG_convertToBSpline(I*8 object, I*8 bspline)
bspline = object.convertToBSpline()
bspline = convertToBSpline(object::Ego)
```

object the input Object (PCURVE, CURVE, EDGE, SURFACE or FACE)

bspline pointer to the returned BSpline Geometry Object

icode the integer return code

Computes and returns the BSpline representation of the input Geometry Object.

Converts geometry (with limits) to BSPLINE mt type

```

icode = EG_convertToBSplineRange(ego object, const double *range,
                                ego *bspline);
icode = IG_convertToBSplineRange(I*8 object, R*8 range,
                                I*8 bspline)

bspline = object.convertToBSpline(range)
bspline = convertToBSplineRange(object::Ego, range::Float[]([]))

```

object the input Object (PCURVE, CURVE or SURFACE)

range t range (2) or $[u, v]$ box (first for u then for $v - 4$) to limit the conversion

bspline pointer to the returned BSpline Geometry Object

icode the integer return code

Required when converting Geometry Objects with infinite range.

oclass	mtype	Notes
MODEL	→	Number of total egos or zero see page 44
BODY	WIREBODY FACEBODY SHEETBODY SOLIDBODY	A single Loop A single Face A single non-manifold or manifold Shell A <i>Solid</i>
SHELL	OPEN or CLOSED	
FACE	SREVERSE or SFORWARD	orientation of surface vs. Face
LOOP	OPEN or CLOSED	
EDGE	DEGENERATE ONENODE TWNODE	a single Node marking the collapse of a surface (nchild = 1) a CLOSED curve (nchild = 1) a normal Edge (nchild = 2)
NODE	–	

Create a Topology Object

dot

```

icode = EG_makeTopology(ego context, ego geom, int oclass, int mtype,
                        double *reals, int nchild, ego *children,
                        int *senses, ego *topo);
icode = IG_makeTopology(I*8 context, I*8 geom, I*4 oclass, I*4 mtype,
                        R*8      reals, I*4 nchild, I*8  children,
                        I*4  senses, I*8  topo)

topo = context.makeTopology(oclass, mtype=0, geom=None, reals=None,
                           children=None, senses=None)

topo = makeTopology!(ctxt::Context, oclass::Int; mtype::Int,
                    geom::Ego, reals::Float[], senses::Int, children::Float([]))

```

context the Context Object

geom the reference Geometry Object (if none use **NULL**)

oclass the Object Class: NODE, EDGE, LOOP, FACE, SHELL, BODY or MODEL

mtype the Member Type (depends on **oclass** – see page 88)

reals the real data: may be **NULL** except for NODE that contains the $[x, y, z]$ location and EDGE where the t_{min} and t_{max} (the parametric bounds) are specified

nchild number of children (lesser) Topological Objects

children vector of children objects (**nchild** in length)

if a LOOP with a reference SURFACE, then $2 * \text{nchild}$ in length (PCurves follow)

senses a vector of children integer senses: SFORWARD/SREVERSE for LOOP, and SOUTER/SINNER for FACE **nchild** > 1 (may be **NULL** for FACE **nchild** = 1)

topo the returned pointer to the new Topology Object

Query a Topology Object 1/2

ET, E1

```

icode = EG_getTopology(ego topo, ego *geom, int *oclass, int *mtype,
                      double *reals, int *nchild, ego **children,
                      int **senses);

icode = IG_getTopology(I*8 topo, I*8 geom, I*4 oclass, I*4 mtype,
                      R*8 reals, I*4 nchild, I*8 children,
                      I*4 senses)

oclass, mtype, geom, reals, children, senses = topo.getTopology()
oclass, mtype, geom, reals, children, senses = getTopology(topo::Ego)

```

- topo** the Topology or *Effective Topology* Object to query
- geom** the returned reference Geometry Object (can be **NULL**)
- oclass** the returned Object Class: Topology or *Effective Topology*
- mtype** the returned Member Type (depends on **oclass** – see page 88)
- reals** the real data (at most 4 **doubles** are filled): NODE – contains the $[x, y, z]$ location, EDGE where the t_{min} and t_{max} (the parametric bounds) are returned and FACE where the $[u, v]$ box is filled → the limits first for u then for v (4 in length)
- nchild** the returned number of children (lesser) Topological Objects
- children** the returned pointer to a vector of children objects (**nchild** in length)
 - if a LOOP with a reference SURFACE, then $2 * \text{nchild}$ in length (PCurves follow)
 - if a MODEL – **nchild** is the number of Body Objects, **mtype** the total **ego** count
- senses** a vector of senses for the children (LOOPS) or inner/outer for (FACES & SHELLS)
- icode** the integer return code (EGADS_OUTSIDE for an open EBody)

Query a Topology Object 2/2

ET

Returns using *Effective Topology*:

EBODY	geom is the source Body Object children are ESHELLs or EFACE (for mtyp is FACEBODY) returns EGADS_OUTSIDE if the EBody is still open
ESHELL	children are EFaces
EFACE	no reference geometry, returns $[u, v]$ box for Face collection children are ELoops
ELOOPX	children are EEdges
EEDGE	no ref geometry, returns t range for the Edge collection children are Nodes

Use EG_getBodyTopos (page 96) on the EBody with **ref** as an EFace and **oclass** as FACE to find all of the Faces in that EFace. The same can be done with Edges/EEdges or use the function EG_effectiveEdgeList (page 156).

Create a Face Object

```
icode = EG_makeFace(ego object, int mtype, const double *rdata,
                    ego *face);
icode = IG_makeFace(I*8 object, I*4 mtype, R*8 rdata,
                    I*8 face)

face = object.makeFace(mtype, rdata=None)
face = makeFace(object::Ego, mtype::Int; rdata::Float[]([]))
```

- object** either a Loop (for a planar cap), a surface with $[u, v]$ bounds, or a Face to be hollowed out
- mtype** is either SFORWARD or SREVERSE. SFORWARD gives a Face normal vector consistent with orientation of the Loop or the normal vector of a surface. Ignored when the input object is a Face
- rdata** may be **NULL** for Loops, but must be the limits for a surface (4 values), the hollow/offset distance and fillet radius (zero is for no fillets) for a Face input object (2 values)
- face** the resultant returned topological Face Object (a return of EGADS_OUTSIDE is the indication that offset distance was too large to produce any cutouts, and this result is the input **object**)
- icode** the integer return code

This *helper* function creates a simple Face from a Loop or a surface. Also can be used to hollow out a Face with a single Loop. This function creates any required Nodes, Edges and Loops.

Create a Loop Object

```
icode = EG_makeLoop(int nedge, ego *edges, ego geom, double toler,
                    ego *loop);
icode = IG_makeLoop(I*4 nedge, I*8 edges, I*8 geom, R*8 toler,
                    I*8 loop)
loop, edges = egads.makeLoop(edges, geom=None, toler=0.0)
loop, edges = makeLoop!(edges::Ego([]); geom::Ego, toler::Float)
```

nedge the number of Edge Objects in the list (≥ 1)

edges list of Edge Objects, of which some may be **NULL** (**nedge** in length)

Note: list entries are **NULL**ified when included in Loops

geom the Surface Object for non-planar Loops to be used to bound Faces (can be **NULL**)

toler tolerance used for the operation (0.0 – use the Edge tolerances)

loop the resultant Loop Object

icode the integer return code or the number of non-**NULL** entries in **edges** when returned

This *helper* function creates a Loop Object from a list of Edge Objects, where the Edges (not DEGENERATE) do not have to be topologically connected. The tolerance is used to build the Nodes for the Loop. The orientation is set by the first non-NULL entry in the list, which is taken in the positive sense (if closed – otherwise the orientation is not fixed). This is designed to be executed until all list entries are exhausted.

Create a simple Solid Body

```
icode = EG_makeSolidBody(ego context, int stype, const double *data,
                        ego *body);
icode = IG_makeSolidBody(I*8 context, I*4 stype, R*8 data,
                        I*8 body)

body = context.makeSolidBody(stype, data)
body = makeSolidBody(context::Ctxt, stype::Int, data::Float[])
```

context the Context Object

stype one of: BOX, SPHERE, CONE, CYLINDER, TORUS

data length and fill depends on **stype**:

BOX	6	$[x, y, z]$ then $[dx, dy, dz]$ for the size of box
SPHERE	4	$[x, y, z]$ of center then the radius
CONE	7	apex $[x, y, z]$, base center $[x, y, z]$, then the radius
CYLINDER	7	2 axis points and the radius
TORUS	8	$[x, y, z]$ of center, direction of rotation, then the major radius and minor radius

body the resultant Solid Body Object

icode the integer return code

Creates a non-manifold Wire Body

```
icode = EG_makeNmWireBody(int nObject, ego *objects, double toler,  
                           ego *wbody);  
icode = IG_makeNmWireBody(I*4 nObject, I*8 objects, R*8 toler,  
                           I*8 wbody)  
wbody = egads.makeNmWireBody(objects, toler=0.0)  
wbody = makeNmWireBody(objects::Ego[]; toler::Float)
```

- nObject** the number of Edge Objects in the list **objects**
objects a pointer to a vector of Edge Objects to make the Wire Body (**nObject** in length)
toler Node tolerance to connect Edges (0.0 indicates the use of the Nodes directly)
wbody the returned pointer to a Wire Body Object
icode the integer return code

Notes:

1. The collection of Edges in **objects** must be connected in a non-manifold manner.
2. If the Edges reflect a simple (manifold) Loop, use `EG_makeTopology` to make the Loop (so that the senses can be set) and then also construct the Wire Body from the Loop.
3. Edges must be given in an order such that every Edge (after the first) creates no more than one new Node.

Queries the Objects in a Body

ET, E1

```

icode = EG_getBodyTopos(const ego body, ego ref, int oclass,
                        int *ntopo, ego **topos);
icode = IG_getBodyTopos(I*8 body, I*8 ref, I*4 oclass,
                        I*4 ntopo, CPTR topos)
topos = object.getBodyTopos(oclass, ref=None)
topos = getBodyTopos(body::Ego, oclass::Int; ref::Ego)

```

body the Body/EBody Object

ref reference Topology Object or **NULL**. Sets the context for the returned Objects (i.e., all objects of the class **oclass** in the tree looking towards that class from **ref**)
NULL starts from the **body** (for example all Nodes in the Body)

oclass is NODE, EDGE, LOOP, FACE or SHELL – must not be the same class as **ref**
 for EBODY can be EEDGE, ELOOPX, EFACE, ESHELL or the above

ntopo the returned number of Topology Objects

topos is a returned pointer to the vector of Objects, it is possible that an individual Object may be **NULL** (*freeable*)

Note: the argument can be **NULL** so the Objects are not filled

icode the integer return code

This allows for the traversal of the Topology *tree* by jumping levels and/or looking up the hierarchy.

Get the index of the Object in a Body

ET, E1

```
index = EG_indexBodyTopo(const ego body, const ego obj);
index = IG_indexBodyTopo(I*8      body, I*8      obj)
index = body.indexBodyTopo(obj)
index = indexBodyTopo(body::Ego, obj::Ego)
```

body the Body/EBody Object

obj is the Topology Object in the Body/EBody

index the index (bias 1) or the integer return code (negative)

Get the Object in a Body by index

ET, E1

```
icode = EG_objectBodyTopo(const ego body, int oclass, int index,
                          ego *obj);
icode = IG_objectBodyTopo(I*8      body, I*4 oclass, I*4 index,
                          I*8      obj)

obj = body.objectBodyTopo(oclass, index)
obj = objectBodyTopo(body::Ego, oclass::Int, index::Int)
```

body the Body/EBody Object

oclass the Topology/*Effective Topology* object class

index the index (bias 1) of the entity requested

obj is the returned Topology Object from the Body/EBody

icode the integer return code

Compute the Area

ET

```

icode = EG_getArea(ego object, const double *limits, double *area);
icode = IG_getArea(I*8 object, R*8 limits, R*8 area)
area = object.getArea(limits=None)
area = getArea(object::Ego; limits::Float[]([]))

```

object either a Loop (for a planar cap), a surface with $[u, v]$ bounds or a Face

limits may be **NULL** except must contain the limits for a surface (4 words)

area the resultant surface area returned

icode the integer return code

Computes the surface area from a Loop, a surface or a Face. The resultant area is negative if a non-planar Loop is left-handed relative to the normal of the associated surface.

Return the Bounding Box info

ET, E1

```

icode = EG_getBoundingBox(const ego object, double *bbox);
icode = IG_getBoundingBox(I*8 object, R*8 bbox)
bbox = object.getBoundingBox()
bbox = getBoundingBox(object::Ego)

```

object any topological object

bbox 6 **doubles** filled reflecting $[x, y, z]_{min}$ and $[x, y, z]_{max}$

icode the integer return code

Computes the smallest Cartesian bounding box surrounding the **object**.

Returns the Mass Properties

ET

```

icode = EG_getMassProperties(const ego object, double *props);
icode = IG_getMassProperties(I*8 object, R*8 props)
volume, areaOrLen, CG, I = object.getMassProperties()
volume, areaOrLen, CG, I = getMassProperties(object::Ego)

```

object can be EDGE, LOOP, FACE, SHELL, BODY or *Effective Topology* counterpart
props 14 **doubles** filled reflecting Volume, Area (or Length), Center of Gravity (3) and the inertia matrix at CG (9)
icode the integer return code

Computes and returns the physical and inertial properties of a Topology Object.
 See EG_tessMassProperties (page 136) if you want derivatives.

Do the two Objects represent the same Topology?

```

icode = EG_isEquivalent(const ego topo1, const ego topo2);
icode = IG_isEquivalent(I*8 topo1, I*8 topo2)
bool = topo1.isEquivalent(topo2)
bool = isEquivalent(topo1::Ego, topo2::Ego)

```

topo1 the first input Topology Object
topo2 the second input Topology Object (to make the comparison)
icode the integer return code (same as EGADS_SUCCESS, not equal is EGADS_OUTSIDE)

Compares two topological objects for equivalence.

Inside Predicate

E1

```
icode = EG_inTopology(const ego object, const double *xyz);  
icode = IG_inTopology(I*8      object, R*8      xyz)  
bool = object.inTopology(xyz)  
bool = inTopology(object::Ego, xyz::Float[])
```

object the object, can be EDGE, FACE, SHELL or SOLIDBODY

xyz the coordinate location to check (3 in length)

icode the integer return code (in is EGADS_SUCCESS, out is EGADS_OUTSIDE)

Computes whether the point is on or contained within **object**. Works with Edges and Faces by projection. Shells must be CLOSED.

In Face Predicate

ET, E1

```
icode = EG_inFace(const ego face, const double *uv);  
icode = IG_inFace(I*8      face, R*8      uv)  
bool = face.inFace(uv)  
bool = inFace(face::Ego, uv::Float[])
```

face the Face Object

uv the $[u, v]$ location to check (2 in length)

icode the integer return code (in is EGADS_SUCCESS, out is EGADS_OUTSIDE)

Queries whether the $[u, v]$ location in the valid part of the Face Object.

Get Edge's UV on Face

ET, E1

```

icode = EG_getEdgeUV(const ego face, const ego edge, int sense,
                    double t, double *uv);
icode = IG_getEdgeUV(I*8 face, I*8 edge, I*4 sense,
                    I*4 t, R*8 uv)
uv = face.getEdgeUV(edge, t, sense=0)
uv = getEdgeUV(face::Ego, edge::Ego, sense::Int, t::Float)

```

face the Face/EFace Object

edge the Edge/EEdge Object

sense can be 0, but must be specified (± 1) if **edge** is found in **face** twice, which denotes the position in the Loop to use.

t the Edge parametric t value

uv the resultant $[u, v]$ – 2 values filled.

icode the integer return code – EGADS_TOPOERR when **sense** is 0 with a double Edge hit.

Notes:

1. Evaluates the Edge/pcurve to get $[u, v]$ on the Face. Use instead of EG_invEvaluate (page 83) at the Face/EFace Object's bounds.
2. Cannot be used on an EFace containing more than one Face and a DEGENERATE EEdge.

Sews unconnected Faces together

```
icode = EG_sewFaces(int nObject, ego *objects, double toler, int flag,
                    ego *model);
icode = IG_sewFaces(I*4 nObject, I*8 objects, R*8 toler, I*4 flag,
                    I*8 model)
model = egads.sewFaces(objects, toler=0.0, manifold=True)
model = sewFaces(objects::Ego[]; toler::Float, flag::Bool)
```

nObject the number of Objects in the list **objects**

objects a pointer to a vector of **egos** to sew together (**nObject** in length)
can be Faces, Shells and/or Body Objects (but not WIREBODY)

toler tolerance used for the operation (0.0 – use Face tolerances)

flag 0 – manifold results

1 – allow for non-manifold results (3 or more Faces connecting to a single Edge)

model the returned pointer to a Model Object

icode the integer return code

Creates a Model from a collection of Objects by *sewing* Edges that are closer together than the tolerance. The input list can contain Body (not WIREBODY), Shell and/or Face Objects. After the sewing operation, any loose Faces are made into FaceBody Objects, any open Shells (or non-manifold results) are made into SheetBody Objects, closed manifold Shells become SolidBody Objects and all are returned in the Model.

Replace Faces in a Body

```
icode = EG_replaceFaces(const ego body, int nFace, ego *objects,  
                        ego *result);  
icode = IG_replaceFaces(I*8 body, I*4 nFace, I*8 objects,  
                        I*8 result)  
result = body.replaceFaces(objects)  
result = replaceFaces(body::Ego, objects::Ego[])
```

body the Body Object to adjust (either a SHEETBODY or a SOLIDBODY)

nFace the number of Face pair Objects in the list **objects**

objects a pointer to a vector of **egos** to sew together ($2*nFace$ in length)
where the first in the pair must be a Face in **body** and second is either the Face to use
as a replacement or a **NULL** which indicates that the Face is to be removed

result the resultant Body Object, either a SHEETBODY or a SOLIDBODY (where the input
was a SOLIDBODY and all Faces are replaced in a way that the Loops match up
– or – if all inner Shell Faces are removed)

icode the integer return code

Creates a new SheetBody or SolidBody Object from an input Body and a list of Faces to modify. The Faces are input in pairs where the first must be an Object in the Body and the second either a new Face or **NULL**. The **NULL** replacement flags removal of the Face.

Removes Nodes from a Body

```

icode = EG_removeNodes(const ego body, int nNode, ego *nodes,
                        ego *result);
icode = IG_removeNodes(I*8 body, I*4 nNode, I*8 nodes,
                        I*8 result)
result = body.removeNodes(nodes)
result = removeNodes(body::Ego, nodes::Ego[])

```

- body** the Body Object to adjust (either a FACEBODY, SHEETBODY or a SOLIDBODY)
- nNode** the number of Node Objects in the list **nodes**
- nodes** a pointer to a vector of NODE **egos** (**nNode** in length)
- result** the resultant Body Object, either a FACEBODY, SHEETBODY or a SOLIDBODY depending on the type of **body**
- icode** the integer return code

Creates a new Body (with the same type as input) from a Body Object and a list of Nodes to remove. The Nodes must only touch 2 Edges and these Edges must bound the same 2 Faces (a SHEETBODY or FACEBODY can bound one Face when on Edges without 2 Face neighbors). If the Edge Curves are not BSplines they are converted and concatenated into a single BSpline Curve and the 2 Edges are replaced by one. Note: you cannot remove a Node that will result in a closed Edge.

Retrieve the Body Object

ET, E1

```
icode = EG_getBody(const ego object, ego *body);  
icode = IG_getBody(I*8 object, I*8 body)  
body = object.getBody()  
body = getBody(body::Ego)
```

object the input topology Object (can be an EBody to retrieve the referenced Body)

body the returned Body/EBody Object (may be **NULL** if **object** is not attached to a Body).
An Effective **object** returns an EBody.

icode the integer return code

Return the Tolerance

E1

```
icode = EG_getTolerance(const ego topo, double *toler);  
icode = IG_getTolerance(I*8 topo, R*8 toler)  
toler = topo.getTolerance()  
toler = getTolerance(topo::Ego)
```

topo the Topology Object

toler the returned tolerance (Effective Topology inputs will return 0.0)

icode the integer return code

Returns the internal tolerance defined for the Object.

Return the Maximum Tolerance

ET, E1

```
icode = EG_tolerance(const ego topo, double *toler);  
icode = IG_tolerance(I*8      topo, R*8      toler)  
toler = topo.tolerance()  
toler = tolerance(topo::Ego)  
    topo  the Topology Object  
    toler the returned tolerance (Effective Topology returns discrete displacement)  
    icode the integer return code
```

Returns the maximum tolerance defined for the Object's hierarchy.

Sets the Tolerance – Deprecated

```
icode = EG_setTolerance(const ego topo, double toler);  
icode = IG_setTolerance(I*8      topo, R*8      toler)  
    topo  the Topology Object  
    toler the specified tolerance  
    icode the integer return code
```

Sets the internal tolerance defined for the object. Was useful for SBOs – now use `EG_generalBoolean` (see page 139).

Find matched Edges between Body Objects

```
icode = EG_matchBodyEdges(const ego body1, const ego body2,  
                           double tolScale, int *nMatch, int **matches)  
icode = IG_matchBodyEdges(I*8 body1, I*8 body2,  
                           R*8 tolScale, I*4 nMatch, CPTR matches)  
matches = body1.matchBodyEdges(body2, tolScale=0.0)  
matches = matchBodyEdges(body1::Ego, body2::Ego; tolScale::Float)
```

body1 the first input Body Object

body2 the second Body Object

tolScale tolerance scale factor, $\text{tolScale} > 1$ relaxes and $1 > \text{tolScale} > 0$ tightens tolerance (may be 0.0 for default tolerances)

nMatch the number of matched Edge pairs in the list

matches pointer to a list of Edge pairs, returned as **NULL** if **nMatch** is zero, otherwise it is a pointer to $2 * \text{nMatch}$ integers, where each pair are the matching 1-bias indices in the respective bodies (freeable)

icode the integer return code

Examines the Edges in one Body against all of the Edges in another. If the number of Nodes, the Node locations, the Edge bounding boxes and the Edge arc-lengths match it is assumed that the Edges match. A list of pairs of 1-bias indices is returned.

Find matched Faces between Body Objects

```

icode = EG_matchBodyFaces(const ego body1, const ego body2,
                           double tolScale, int *nMatch, int **matches)
icode = IG_matchBodyFaces(I*8      body1, I*8      body2,
                           R*8      tolScale, I*4  nMatch, CPTR matches)
matches = body1.matchBodyFaces(body2, tolScale=0.0)
matches = matchBodyFaces(body1::Ego, body2::Ego; tolScale::Float)

```

body1 the first input Body Object

body2 the second Body Object

tolScale tolerance scale factor, $\text{tolScale} > 1$ relaxes and $1 > \text{tolScale} > 0$ tightens tolerance (may be 0.0 for default tolerances)

nMatch the number of matched Face pairs in the list

matches pointer to a list of Face pairs, returned as **NULL** if **nMatch** is zero, otherwise it is a pointer to $2 * \text{nMatch}$ integers, where each pair are the matching 1-bias indices in the respective bodies (freeable)

icode the integer return code

Examines the Faces in one Body against all of the Faces in another. If the number of Loops, number of Nodes, the Node locations, number of Edges, the Face and Edge bounding boxes and the Edge arc-lengths match it is assumed that the Faces match. A list of pairs of 1-bias indices is returned.

Note: This is useful for the situation where there are glancing Faces and a UNION operation fails (or would fail). Simply find the matching Faces and do not include them in a call to `EG_sewFaces`, see page 102.

Maps the Objects of the Source to the Destination

```
icode = EG_mapBody(const ego src, const ego dst,  
                  const char *fAttr, ego *mapped);  
icode = IG_mapBody(I*8      src, I*8      dst,  
                  C**      fAttr, I*8     mapped)  
mapped = src.mapBody(dst, fAttr)  
mapped = mapBody(src::Ego, dst::Ego, fAttr::String)
```

src the source Body Object (not a WIREBODY)

dst the destination Body Object

fAttr the Face attribute used to map the Faces

mapped the mapped resultant Body Object copied from **dst**

If **NULL** and **icode** is EGADS_SUCCESS, **dst** is equivalent and can be used directly in EG_mapTessBody – see page 118.

icode the integer return code

Checks for topological equivalence between **src** and **dst**. If necessary, produces a mapping (indices in **src** which map to **dst**) and places these as body attributes on **mapped** (named “.nMap”, “.eMap” and “.fMap”). Also may modify BSplines associated with Faces.

Note: It is the responsibility of the caller to have uniquely attributed all Face Objects in both **src** and **dst** to aid in the mapping for all but FACEBODYs.

Maps the Objects of the Source to the Destination

```
icode = EG_mapBody2(const ego src, const char *fAttr,  
                    const char *eAttr, ego dst);  
icode = IG_mapBody2(I*8 src, C** fAttr,  
                    C** eAttr, I*8 dst)  
src.mapBody2(fAttr, eAttr, dst)  
mapBody2(src::Ego, fAttr::String, eAttr::String, dst::Ego)
```

src the source Body Object

dst the destination Body Object

fAttr the Face attribute used to map the Faces

eAttr the Edge attribute used to map the Edges

icode the integer return code

Checks for topological equivalence between **src** and **dst**. If necessary, produces a mapping (indices in **src** which map to **dst**) and places these as body attributes on **dst** (named “.nMap”, “.eMap” and “.fMap”). Unlike EG_mapBody, EG_mapBody2 also works on FACEBODYS and WIREBODYS.

Note: It is the responsibility of the caller to have uniquely attributed all Face and non degenerate Edge Objects in both **src** and **dst** to aid in the mapping.

Computes the Winding Angle along an Edge

E1

```
icode = EG_getWindingAngle(ego edge, double t, double *angle);  
icode = IG_getWindingAngle(I*8 edge, R*8 t, R*8 angle)  
angle = edge.getWindingAngle(t)  
angle = getWindingAngle(edge::Ego, t::Float)
```

edge the input Edge (not DEGENERATE)

returns an error if there are 3 or more Faces attached to the Edge

t the t value along the Edge used to compute the Winding Angle

angle the returned Winding Angle in degrees (0.0 – 360.0)

This is measured from one Face “winding” around to the other based on the normals

An Edge with a single Face always returns 180.0

icode the integer return code

Creates a Discrete Object from Geometry

```

icode = EG_makeTessGeom(ego geom, double *limits, int *sizes,
                        ego *tess);
icode = IG_makeTessGeom(I*8 geom, R*8 limits, I*4 sizes,
                        I*8 tess)

tess = geom.makeTessGeom(limits, sizes)
tess = makeTessGeom(geom::Ego, limits::Float[], sizes::Int[])

```

geom the input Object, may be a CURVE or SURFACE

limits the bounds of the tessellation (like input like the *range* – see EG_getRange, page 81)

sizes a set of 2 integers that specifies the size and dimensionality of the data. The second is assumed zero for a CURVE and in this case the first integer is the length of the number of evenly spaced (in t) points created. The second integer must be nonzero for SURFACES and this then specifies the density of the $[u, v]$ map of coordinates produced (again evenly spaced in the parametric sense). If a value of sizes is negative, then the fill is reversed for that coordinate.

tess the returned resultant Tessellation of the geometric entity

icode the integer return code

Creates a discretization object from a geometry-based Object.

Returns the Discrete Object data

```
icode = EG_getTessGeom(ego tess, int *sizes, double **xyzs);  
icode = IG_getTessGeom(I*8 tess, I*4 sizes, CPTR xyzs)  
sizes, xyzs = tess.getTessGeom()  
sizes, xyzs = getTessGeom(tess::Ego)
```

tess the input geometric Tessellation Object

sizes a returned (filled) set of 2 integers that specifies the size and dimensionality of the data. If the second is zero, then it is from a CURVE and the first integer is the length of the number of $[x, y, z]$ triads. If the second integer is nonzero then the input data reflects a 2D map of coordinates.

xyzs the returned pointer to the suite of coordinate data

icode the integer return code

Retrieves the data associated with the discretization of a geometry-based Object.

Creates a Discrete Object from a Body

ET, E1

```
icode = EG_makeTessBody(ego body, double *parms, ego *tess);  
icode = IG_makeTessBody(I*8 body, R*8      parms, I*8  tess)  
    tess = body.makeTessBody(parms)  
    tess = makeTessBody(body::Ego, parms::Float[])
```

body the input Body or closed EBody Object, may be any Body type

parms a set of 3 parameters that drive the Edge discretization and the Face triangulation. The first is the maximum length of an Edge segment or triangle side (in physical space); a zero is no limit, and a negative value only tessellates Edges. The second is a curvature-based value that looks locally at the deviation between the centroid of the discrete object and the underlying geometry. Any deviation larger than the input value will cause the tessellation to be enhanced in those regions. The third is the maximum interior dihedral angle (in degrees) between triangle facets (or Edge segment tangents for a WIREBODY tessellation), note that a zero ignores this phase.

tess the returned resultant Tessellation of **body**

icode the integer return code

See the next page for attribute-based tessellation control.

Tessellation control at the Topological level

- .tParams** this attribute can be placed on the Body, individual Faces or Edges which overrides **parms** locally (the minimums are used). This attribute must be ATTRREAL and have 3 values (as described in EG_makeTessBody).
- .tParam** like the attribute **.tParams**, this attribute completely overrides **parms** locally (without using the minimum).
- .tPos** this ATTRREAL attribute on an Edge directly sets the ts for interior Edge positions.
- .rPos** this ATTRREAL attribute sets the relative spacing (in arc-length) for interior Edge positions.
- .nPos** this ATTRINT attribute sets the number of interior vertices (length is 1). The spacing is set equal in arc-length.
- .inserts** this ATTRREAL attribute (on a Face) specifies that these vertex $[u, v]$ positions will be inserted into the tessellation. The length must be 2 times the number of inserts.
- .insert!** like the attribute **.inserts**, this specifies the $[u, v]$ positions to be inserted, but after these inserts the Face tessellation terminates (i.e., no additional insertions are performed by the normal algorithm).

note:

An ATTRINT attribute **.tPos** or **.rPos** of length 1 and containing a zero indicates no interior points.

Convert a Triangulation to Quads

ET, E1

```

icode = EG_quadTess(ego tess, ego *qtess);
icode = IG_quadTess(I*8 tess, I*8 qtess)
qtess = tess.quadTess()
qtess = quadTess(tess::Ego)

```

tess the input Tessellation Object (not for WIREBODY)
qtess the returned fully quadrilateral Tessellation Object
icode the integer return code

Takes a triangulation as input and outputs a full quadrilateralization of the Body. The algorithm uses the bounds of each Face (the discretization of the Loops) and drives the interior towards regularization (4 quad sides attached to a vertex) without regard to spacing but maintaining a valid mesh. This is the recommended quad approach in that it is robust and does not require manual intervention like EG_makeQuads – page 123 (plus retrieving the quads is much simpler and does not require invoking EG_getQuads – page 125 and EG_getPatch – page 126).

qtess is a triangle-based Tessellation Object, but with pairs of triangles (as retrieved by calls to EG_getTessFace – page 121) representing each quadrilateral. This is marked by the following attributes on **qtess**:

- “.tessType” (ATTRSTRING) is set to “Quad”
- “.mixed” with type ATTRINT and the length is the number of Faces in the Body, where the values are the number of quads (triangle pairs) per Face. Single triangles are followed by triangle pairs for a Face with both triangle and quads.

Redoes parts of the tessellation for a Body

ET, E1

```

icode = EG_remakeTess(ego tess, int nobj, ego *facedg, double *parms);
icode = IG_remakeTess(I*8 tess, I*4 nobj, I*8 facedg, R*8 parms)
    tess.remakeTess(facedg, parms)
    remakeTess!(tess::Ego, facedg::Ego[], parms::Float[])

```

- tess** the Tessellation Object to modify
- nobj** number of Objects in the Face/Edge list
- facedg** a pointer to a list of Face and/or Edge Objects from within the source Body used to create the Tessellation Object. First all specified Edges are rediscritized. Then any listed Face and the Faces touched by the retessellated Edges are retriangulated. Note that Quad Patches associated with Faces whose Edges were redone will be removed.
- parms** a set of 3 parameters that drive the Edge discretization and the Face triangulation. The first is the maximum length of an Edge segment or triangle side (in physical space). A zero is flag that allows for any length. The second is a curvature-based value that looks locally at the deviation between the centroid of the discrete object and the underlying geometry. Any deviation larger than the input value will cause the tessellation to be enhanced in those regions. The third is the maximum interior dihedral angle (in degrees) between triangle facets (or Edge segment tangents for a WIREBODY tessellation), note that a zero ignores this phase.
- icode** the integer return code

Redoes the discretization for specified Objects from within a Body Tessellation.

Places the tessellation from one Body onto another

```
icode = EG_mapTessBody(ego tess, ego body, ego *newTess);  
icode = IG_mapTessBody(I*8 tess, I*8 body, I*8 newTess)  
newTess = tess.mapTessBody(body)  
newTess = mapTessBody(tess::Ego, body::Ego)
```

tess the Body Tessellation Object used to create the tessellation on **body**

body the Body Object (with a matching Topology) used to map the tessellation

newTess the returned resultant Tessellation of **body**. The triangulation is simply copied but the $[u, v]$ and $[x, y, z]$ positions reflect the input Body (**body**).

icode the integer return code

Maps the input discretization object to another Body Object. The topologies of the Body that created the input tessellation must match the topology of the body argument. The use of `EG_mapBody` (page 109) or `EG_mapBody2` (page 110) can assist. Can be useful for finite differences.

Note: Invoking `EG_moveEdgeVert` (page 127), `EG_deleteEdgeVert` (page 127) and/or `EG_insertEdgeVerts` (page 128) in the source tessellation before calling this routine invalidates the ability of `EG_mapTessBody` to perform this function.

Provides a mapping for requested points

```

icode = EG_locateTessBody(const ego tess, int npts, const int *ifaces,
                        const double *uv, int *tris, double *weight);
icode = IG_locateTessBody(I*8 tess, I*4 npts, I*4 ifaces,
                        R*8 uv, I*4 tris, R*8 weight)

weight, tris = tess.locateTessBody(ifaces, uv, mapped=False)
weight, tris = locateTessBody(tess::Ego, ifaces::Int[],
                             uv::Float[] ([]), mapped::Bool)

```

- tess** the input Body Tessellation Object
- npts** the number of input requests
- ifaces** the face indices for each request; minus index refers to the use of a mapped Face index from EG_mapBody (page 109) & EG_mapTessBody (page 118) – **npts** in length
- uv** the $[u, v]$ positions in the Face for each request – $2*\mathbf{npts}$ in length
- tris** the resultant 1-bias triangle index – **npts** in length
if input as **NULL** then this function will perform mapped evaluations
- weight** the vertex weights in the triangle that refer to the requested position (any negative weight indicates that the point was extrapolated) –or– the evaluated position based on the input **uvs** (when **tris** is **NULL**)
 $3*\mathbf{npts}$ in length
- icode** the integer return code

Provides the triangle and the vertex weights for each of the input requests or the evaluated positions in a mapped tessellation.

Gets the Edge discretization data

ET, E1

```

icode = EG_getTessEdge(const ego tess, int eIndex, int *len,
                      const double **xyzs, const double **ts);
icode = IG_getTessEdge(I*8 tess, I*4 eIndex, I*4 len,
                      R*8 xyzs, R*8 ts)

xyzs, ts = tess.getTessEdge(eIndex)
xyzs, ts = getTessEdge(tess::Ego, eIndex::Int)

```

- tess** the input Body Tessellation Object
- eIndex** the Edge index (1 bias). The Edge Objects and number of Edges can be retrieved via EG_getBodyTopos (page 96) and/or EG_indexBodyTopo (page 97). A minus index refers to the use of a mapped (+) Edge index from applying the functions EG_mapBody (page 109) and EG_mapTessBody (page 118).
- len** the returned number of vertices in the Edge discretization
- xyzs** the returned pointer to the set of coordinate data – **3*len** in length
- ts** the returned pointer to the parameter values associated with each vertex – **len** in length
- icode** the integer return code

Note: DEGENERATE Edges return 2 vertices (both the same coordinates of the single Node) and the *t* range in **ts**. This Edge will not be referenced in the associated Face tessellation.

Gets the Face triangulation data

ET, E1

```

icode = EG_getTessFace(const ego tess, int fIndex, int *len,
                      const double **xyz, const double **uv,
                      const int **ptype, const int **pindx, int *ntri,
                      const int **tris, const int **tric);
icode = IG_getTessFace(I*8 tess, I*4 fIndex, I*4 len,
                      R*8 xyz, R*8 uv,
                      I*4 ptype, I*4 pindx, I*4 *ntri,
                      I*4 tris, I*4 tric)
xyz, uv, ptype, pindx, tris, tric = tess.getTessFace(fIndex)
xyz, uv, ptype, pindx, tris, tric = getTessFace(tess::Ego, fIndx::Int)

```

- tess** the input Body Tessellation Object
- fIndex** the Face index (1 bias)
- len** the returned number of vertices in the Face triangulation
- xyz** the returned pointer to the set of coordinate data – 3***len** in length
- uv** the returned pointer to the parameters for each vertex – 2***len** in length
- ptype** returned pointer to the vertex type (-1 - internal, 0 - Node, > 0 Edge) – **len** in length
- pindx** returned pointer to vertex index (-1 internal) – **len** in length
- ntri** returned number of triangles
- tris** returned pointer to triangle indices, 3 per triangle (1 bias) – 3***ntri** in length
- tric** returned pointer to neighbor information, 3 per triangle looking at opposing side: triangle (1-ntri), negative is Edge index for an external side – 3***ntri** in length

Gets the Discrete Loop data

ET, E1

```

icode = EG_getTessLoops(const ego tess, int fIndex, int *nloop,
                        const int **lIndices);
icode = IG_getTessLoops(I*8 tess, I*4 fIndex, I*4 nloop,
                        I*4 lIndices)

lIndices = tess.getTessLoops(fIndex)
lIndices = getTessLoops(tess::Ego, fIndex::Int)

```

tess the input Body Tessellation Object

fIndex the Face index (1 bias). The Face Objects and number of Faces can be retrieved via EG_getBodyTopos and/or EG_indexBodyTopo.

nloop the returned number of Loops in the Face triangulation

Indices the returned pointer to a vector of the last index (bias 1) for each Loop – **nloop** in length. Notes:

- ① all boundary vertices are listed first for any Face tessellation,
- ② outer Loop data is ordered in the counter-clockwise direction, and
- ③ inner Loop(s) are ordered in the clockwise direction.

icode the integer return code

Retrieves the data for the Loops associated with the discretization of a Face from a Body-based Tessellation Object.

Manually ask for quads

ET, E1

```
icode = EG_makeQuads(ego tess, double *qparms, int fIndex);  
icode = IG_makeQuads(I*8 tess, R*4 qparms, I*4 fIndex)  
    tess.makeQuads(qparms, fIndex)  
    makeQuads!(tess::Ego, qparms::Float[], fIndex::Int)
```

tess the input Body Tessellation Object

qparms a set of 3 parameters that drive the Quadrilateral patching for the Face. Any may be set to zero to indicate the use of the default value:

- **qparms[0]** – Edge matching tolerance expressed as the deviation from an aligned dot product [*default* : 0.05]
- **qparms[1]** – Maximum quad *side ratio* point count to allow [*default* : 3.0]
- **qparms[2]** – Number of smoothing loops [*default* : 0.0]

fIndex the Face index (1 bias)

icode the integer return code

Creates Quadrilateral Patches for the indicated Face and updates the Body-based Tessellation Object (if possible).

Note: you may want to consider using EG_quadTess (page 116) instead.

Ask for Faces with Quad Patches

ET, E1

```
icode = EG_getTessQuads(ego tess, int *nface, int **fList);  
icode = IG_getTessQuads(I*8 tess, I*4 nface, I*4 fList)  
fList = tess.getTessQuads()  
fList = getTessQuads(tess::Ego)
```

- tess** the Body Tessellation Object
- nface** the returned number of Faces with Quad patches
- fList** the returned pointer the Face indices (1 bias) – **nface** in length (freeable)
The Face Objects themselves can be retrieved via EG_getBodyTopos
- icode** the integer return code

Returns a list of Face indices found in the Body-based Tessellation Object that has been successfully Quadded via EG_makeQuads – page 123.

Gets the Quad Face data

ET, E1

```

icode = EG_getQuads(const ego tess, int fIndex, int *len,
                    const double **xyz, const double **uv,
                    const int **ptype, const int **pindx, int *npatch);
icode = IG_getQuads(I*8 tess, I*4 fIndex, I*4 len,
                    R*8 xyz, R*8 uv,
                    I*4 ptype, I*4 pindx, I*4 *npatch)
xyz, uv, ptype, pindx, npatch = tess.getQuads(fIndex)
xyz, uv, ptype, pindx, npatch = getQuads(tess::Ego, fIndex::Int)

```

tess the input Body Tessellation Object
fIndex the Face index (1 bias)
len the returned number of vertices in the Face triangulation
xyz the returned pointer to the set of coordinate data – 3***len** in length
uv the returned pointer to the parameters for each vertex – 2***len** in length
ptype returned pointer to the vertex type (-1 - internal, 0 - Node, > 0 Edge) – **len** in length
pindx returned pointer to vertex index (-1 internal) – **len** in length
npatch returned number of patches
icode the integer return code

Retrieves the data associated with the Quad-patching of a Face (using EG_makeQuads – page 123) in a Body-based Tessellation Object.

Gets the Quad Face patch data

ET, E1

```

icode = EG_getPatch(const ego tess, int fIndex, int pIndex,
                    int *n1, int *n2, const int **pvindex,
                    const int **pbounds);
icode = IG_getPatch(I*8 tess, I*4 fIndex, I*4 pIndex,
                    I*4 n1, I*4 n2, CPTR pvindex,
                    CPTR pbounds)
n1, n2, pvindex, pbounds = tess.getPatch(fIndex, pIndex)
n1, n2, pvindex, pbounds = getPatch(tess::Ego, fIndex::Int,
                                     pIndex::Int)

```

- tess** the input Body Tessellation Object
- fIndex** the Face index (1 bias)
- pIndex** the Patch index (from 1 to **npatch** returned by EG_getQuads)
- n1** the returned patch size in the first direction (indexed by *i*)
- n2** the returned patch size in the second direction (indexed by *j*)
- pvindex** the returned pointer to $n1 * n2$ indices that define the patch
- pbounds** returned pointer to the neighbor bounding information for the patch. The first represents the segments at the base (*j* at base and increasing in *i*), the next is at the right (with *i* at max and *j* increasing). The third is the top (with *j* at max and *i* decreasing) and finally the left (*i* at min and *j* decreasing). $(2 * (n1 - 1) + 2 * (n2 - 1))$ in length

Retrieves the patch data associated with the Quad data on a Face (generated by EG_makeQuads – page 123) in a Body-based Tessellation Object.

Move the position of an Edge Vertex

ET, E1

```
icode = EG_moveEdgeVert(ego tess, int eIndex, int vIndex, double t);
icode = IG_moveEdgeVert(I*8 tess, I*4 eIndex, I*4 vIndex, R*8 t)
    tess.moveEdgeVert(eIndex, vIndex, t)
    moveEdgeVert!(tess::Ego, eIndex::Int, vIndex::Int, t::Float)
```

tess the Body Tessellation Object (not on WIREBODIES)
eIndex the Edge index (1 bias)
vIndex the Vertex index in the Edge (2 to **nVert**-1)
t the new parameter value on the Edge for the point

Note: Will invalidate the Quad patches on any Faces touching the Edge.

Deletes an Edge Vertex

ET, E1

```
icode = EG_deleteEdgeVert(ego tess, int eIndex, int vIndex, int dir);
icode = IG_deleteEdgeVert(I*8 tess, I*4 eIndex, I*4 vIndex, I*4 dir)
    tess.deleteEdgeVert(eIndex, vIndex, dir)
    deleteEdgeVert!(tess::Ego, eIndex::Int, vIndex::Int, dir::Int)
```

tess the Body Tessellation Object (not on WIREBODIES)
eIndex the Edge index (1 bias)
vIndex the Vertex index in the Edge (2 to **nVert**-1)
dir the direction to collapse any triangles (either -1 or 1)

Note: Will invalidate the Quad patches on any Faces touching the Edge.

Insert vertices on an Edge

ET, E1

```

icode = EG_insertEdgeVerts(ego tess, int eIndex, int vIndex, int len,
                           double *ts);
icode = IG_insertEdgeVerts(I*8 tess, I*4 eIndex, I*4 vIndex, I*4 len,
                           R*8      ts)
tess.insertEdgeVerts(eIndex, vIndex, ts)
insertEdgeVerts!(tess::Edge, eIndex::Int, vIndex::Int, ts::Float([]))

```

- tess** the Body Tessellation Object (not on WIREBODIES)
- eIndex** the Edge index (1 bias)
- vIndex** the Vertex index in the Edge (2 to **nVert**-1)
- len** the number of points to insert
- ts** a vector of *t* values for the new points. Must be monotonically increasing and be greater than the *t* of **vIndex** and less than the *t* of **vIndex**+1.
- icode** the integer return code

Note: Will invalidate the Quad patches on any Faces touching the Edge.

Open an existing Tessellation Object

ET, E1

```
icode = EG_openTessBody(ego tess);  
icode = IG_openTessBody(I*8 tess)  
    tess.openTessBody()  
    openTessBody(tess::Ego)
```

tess the Tessellation Object to open

icode the integer return code

Opens an existing Tessellation Object for replacing Edge/Face discretizations.

Open a new (empty) Tessellation Object

ET, E1

```
icode = EG_initTessBody(ego body, ego *tess);  
icode = IG_initTessBody(I*8 body, I*8 tess)  
    tess = body.initTessBody()  
    tess = initTessBody(body::Ego)
```

body the input object, may be any Body type

tess resultant empty Tessellation Object where each Edge in the BODY must be filled via a call to EG_setTessEdge (page 131) and each Face must be filled with invocations of EG_setTessFace (page 132). The Tessellation Object is considered open until all Edges have been set (for a WIREBODY), all Faces have been set (for other Body types) or EG_finishTess (page 134) is called.

icode the integer return code

Status of a Tessellation Object

ET, E1

```

icode = EG_statusTessBody(ego tess, ego *body, int *stat, int *npts);
icode = IG_statusTessBody(I*8 tess, I*8 body, I*4 stat, I*4 npts)
body, stat, icode, npts = tess.statusTessBody()
body, stat, icode, npts = statusTessBody(tess::Ego)

```

- tess** the Tessellation Object to query
- body** the returned associated Body Object
- stat** the returned state of the tessellation: -1 – closed but warned, 0 – open, 1 – OK, 2 – displaced
- npts** the returned number of global points in the tessellation (0 – open)
- icode** the integer return code: EGADS_SUCCESS – complete, EGADS_OUTSIDE – still open

Note: Placing the attribute “.mixed” on **tess** before invoking this function allows for tri/quad (2 tris) tessellations. The type must be ATTRINT and the length is the number of Faces, where the values are the number of quads (triangle pairs) per Face. Single triangles are followed by triangle pairs for a Face with both triangle and quads.

Given quad 1 2 3 4 ==>	4---3
trias 1 2 3 and 1 3 4	/
	1---2

Sets the Edge discretization data

ET, E1

```

icode = EG_setTessEdge(ego tess, int eIndex, int len,
                      const double *xyzs, const double *ts);
icode = IG_setTessEdge(I*8 tess, I*4 eIndex, I*4 len,
                      R*8 xyzs, R*8 ts)
tess.setTessEdge(eIndex, xyzs, ts)
setTessEdge!(tess::Ego, eIndex::Int, xyzs::Float[][], ts::Float[])

```

- tess** the open Tessellation Object
- eIndex** the Edge index (1 bias). The Edge Objects and number of Edges can be retrieved via EG_getBodyTopos and/or EG_indexBodyTopo. If this Edge already has assigned data, it is overwritten.
- len** the number of vertices in the Edge discretization
- xyzs** the pointer to the set of coordinate data – 3*len in length
- ts** the pointer to the parameter values associated with each vertex – len in length
- icode** the integer return code

Notes:

- 1 all vertices must be specified in increasing t
- 2 the coordinates for the first and last vertex MUST match the appropriate Node's coordinates
- 3 problems are reported to *Standard Out* regardless of the OutLevel

Sets the Face triangulation data 1/2

ET, E1

```

icode = EG_setTessFace(ego tess, int fIndex, int len,
                      const double *xyz, const double *uv,
                      int ntri, const int *tris);
icode = IG_setTessFace(I*8 tess, I*4 fIndex, I*4 len,
                      R*8 xyz, R*8 uv,
                      I*4 ntri, I*4 tris)
tess.setTessFace(fIndex, xyz, uv, tris)
setTessFace!(tess::Ego, fIndex::Int, xyz::Float[][],
             uv::Float[][], tris::Int[][])

```

- tess** the open Body Tessellation Object
- fIndex** the Face index (1 bias). The Face Objects and number of Faces can be retrieved via EG_getBodyTopos and/or EG_indexBodyTopo. If this Face already has assigned data, it is overwritten.
- len** the number of vertices in the Face triangulation
- xyz** the pointer to the set of coordinate data – 3*len in length
- uv** the pointer to the parameters for each vertex – 2*len in length
- ntri** returned number of triangles
- tris** the pointer to triangle indices, 3 per triangle (1 bias) – 3*ntri in length
- icode** the integer return code

Sets the Face triangulation data 2/2

ET, E1

Notes:

- 1 All Edges associated with the Face must have been set
- 2 Any vertex associated with a Node or an Edge must use the exact coordinates specified by the Node or the Edge discretization
- 3 During the execution of `EG_setTessFace` the vertices that are input will go through renumbering. This is because there is an internal assumption that the first suite of coordinates represent the Edge tessellation ordered by the Loops found in the Face. This is usually fine, but there are circumstances that you may need to know the mapping, so that later you can find specific a specific vertex. This can be reverse engineered by maintaining the initial triangle list, calling `EG_getTessFace` – page 121 (after the invocation of `EG_setTessFace`) and using the triangles to construct the index mapping. To state it in another way: the triangle order is fixed but the list of vertices has been rearranged.
- 4 Problems are reported to *Standard Out* regardless of the `OutLevel`

Finish up and close an Open Tessellation Object *ET, E1*

```
icode = EG_finishTess(ego tess, double *parms);  
icode = IG_finishTess(I*8 tess, R*8      parms)  
    tess.finishTess(parms)  
    finishTess!(tess::Ego, parms::Float[])
```

tess the Open Tessellation Object to close

parms a set of 3 parameters that drive the Edge discretization and the Face triangulation. The first is the maximum length of an Edge segment or triangle side (in physical space). A zero is flag that allows for any length. The second is a curvature-based value that looks locally at the deviation between the centroid of the discrete object and the underlying geometry. Any deviation larger than the input value will cause the tessellation to be enhanced in those regions. The third is the maximum interior dihedral angle (in degrees) between triangle facets (or Edge segment tangents for a WIREBODY tessellation), note that a zero ignores this phase.

icode the integer return code

Completes the discretization for unfilled entities found within the input Tessellation Object.

Note: an open Tessellation Object is created by `EG_initTessBody` (page 129) and can be partially filled via `EG_setTessEdge` (page 131) and/or `EG_setTessFace` (page 132) before this function is invoked.

Global Lookup

ET, E1

```

icode = EG_localToGlobal(const ego tess, int ind, int locl, int *gbl);
icode = IG_localToGlobal(I*8 tess, I*4 ind, I*4 locl, int gbl)
    gbl = tess.localToGlobal(ind, locl)
    gbl = localToGlobal(tess::Ego, ind::Int, locl::Int)
    tess the closed Tessellation Object
    ind the topological index (1 bias) – 0 Node, (-) Edge, (+) Face
    locl the local (or Node) index
    gbl the returned global vertex index

```

Gets the vertex type and index

ET, E1

```

icode = EG_getGlobal(const ego tess, int global, int *pytpe,
                    int *pindex, double *xyz);
icode = IG_getGlobal(I*8 tess, I*4 global, I*4 pytpe,
                    I*4 pindex, R*8 xyz)
pytpe, pindex, xyz = tess.getGlobal(global)
pytpe, pindex, xyz = getGlobal(tess::Ego, global::Int)
    tess the closed Tessellation Object
    global the global index (1 bias)
    pytpe the point type (-) Face local index, (0) Node, (+) Edge local index
    pindex the point topological index (1 bias)
    xyz the filled (3 in length) coordinates at this global index (can be NULL)

```

Returns the Discrete Mass Properties

dot

```
icode = EG_tessMassProps(const ego tess, double *props);  
icode = IG_tessMassProps(I*8 tess, R*8 props)  
volume, aeraOrLen, CG, I = tess.tessMassProps()  
volume, aeraOrLen, CG, I = tessMassProps(tess::Ego)
```

- tess** the Body Tessellation Object used to compute the Mass Properties
- props** 14 **doubles** filled reflecting Volume, Area (or Length), Center of Gravity (3) and the inertia matrix at CG (9)
- icode** the integer return code

Computes and returns the physical and inertial properties of a Tessellation Object.

Write Tessellation to Disk – Deprecated

```
icode = EG_saveTess(ego tess, const char *filename);  
icode = IG_saveTess(I*8 tess, C**      filename)
```

tess the closed Tessellation Object

filename the filename (including extension)

icode the integer return code

The extension can be anything, but it is suggested that “.eto” (EGADS Tessellation Object) be used.

Read Tessellation from Disk – Deprecated

```
icode = EG_loadTess(ego body, const char *filename, ego *tess);  
icode = IG_loadTess(I*8 body, C**      filename, I*8 tess)
```

body the Body Object to attach the tessellation from the file

filename the filename (including extension) to load

tess the returned Tessellation Object

icode the integer return code

Perform the Solid Boolean Operations – Deprecated

```
icode = EG_solidBoolean(const ego src, const ego tool, int oper,  
                        ego *model);  
icode = IG_solidBoolean(I*8 src, I*8 tool, I*4 oper,  
                        I*8 model)
```

src the source SOLIDBODY Body Object

tool the tool object:

either a SOLIDBODY for all operators –or–
a FACE/FACEBODY for SUBTRACTION

oper one of: INTERSECTION, SUBTRACTION, FUSION

model the resultant Model Object (this is because there may be multiple bodies from either the SUBTRACTION or INTERSECTION operation).

icode the integer return code

Performs the Solid Boolean Operations (SBOs) on the source Body Object (that has the type SOLIDBODY). The tool Object types depend on the operation. This supports Intersection, Subtraction and Union.

Note: This may be called with **src** being a Model Object. In this case **tool** may be a SOLIDBODY for Intersection/Subtraction or a FACE/FACEBODY for Fusion. The input Model Object may contain anything, but must not have duplicate topology.

Perform the Boolean Operations

```
icode = EG_generalBoolean(ego src, ego tool, int oper, double tol,  
                           ego *model);  
icode = IG_generalBoolean(I*8 src, I*8 tool, I*4 oper, R*8 tol,  
                           I*8 model)  
model = src.generalBoolean(tool, oper, tol=0.0)  
model = generalBoolean(src::Ego, tool::Ego, oper::Int; tol::Real)
```

src the source in the form of a Model or Body Object

tool the tool in the form of a Model or Body Object

oper one of: INTERSECTION, SUBTRACTION, FUSION, SPLITTER

tol the tolerance applied when performing the operation. If set to 0.0, the minimum tolerance is applied

model the returned resultant Model Object (this is because there may be multiple bodies from either the SUBTRACTION or INTERSECTION operation).

icode the integer return code

Performs the Boolean Operations on the source Body Object(s). The tool Body Object(s) are applied depending on the operation. This supports Intersection, Splitter, Subtraction and Union.

Note: The Body Object(s) for **src** and **tool** can be of any type and the results depend on the operation.

Perform a Union on Sheet Bodies

```
icode = EG_fuseSheets(ego src, ego tool, ego *sheet);  
icode = IG_fuseSheets(I*8 src, I*8 tool, I*8 sheet)  
sheet = src.generalBoolean(tool)  
sheet = fuseSheets(src::Ego, tool::Ego)
```

src the source Sheet Body Object

tool the tool Sheet Body Object

sheet the returned resultant Body Object (mttype is SHEETBODY).

icode the integer return code

Fuses (unions) two Sheet Body Objects resulting in a single Sheet Body Object.

Provide the Intersection

```
icode = EG_intersection(ego src, ego tool, int *nEdge, ego **pairs,  
                        ego *model);  
icode = IG_intersection(I*8 src, I*8 tool, I*4 nEdge, I*8 pairs,  
                        I*8 model)  
pairs, model = src.intersection(tool)  
pairs, model = intersection(src::Ego, tool::Ego)
```

- src** the source Body (FACEBODY/SHEETBODY/SOLIDBODY) Object
tool the FACE/FACEBODY/SHEETBODY/SOLIDBODY tool Object
nEdge the returned number of Edge Objects created
pairs the returned pointer to Face/Edge Object pairs – 2***nEdge** in len (freeable)
can be **NULL** (if you don't need the data – the Edge Objects are in **model**)
model the resultant Model Object which contains the set of WIREBODY Objects (this is
because there may be multiple Loop Objects as a result of the operation). Deleting
model invalidates the data in **pairs**.
icode the integer return code

Intersects the source Body Object with the tool Object and returns the intersection fragments.

- Notes: 1) The new Edge Objects have the attributes of the Face Object in **src** cut for that Edge.
2) If the total number of Edges in **model** does not match **nEdge** there has been an intersection that
is coincident with existing Edge(s). **model** must be parsed to determine what Edge(s) require
splitting. EG_imprintBody will probably not currently work under these circumstances.

Scribe a Body

```
icode = EG_imprintBody(ego src, int nObj, ego *pairs, ego *result);  
icode = IG_imprintBody(I*8 src, I*4 nObj, I*8 pairs, I*8 result)  
result = src.imprintBody(pairs)  
result = imprintBody(src::Ego, pairs::Ego[[]])
```

- src** the source Body Object
- nObj** the number of Object pairs to imprint
- pairs** pointer to a list of Face/Edge and/or Face/Loop Object pairs to scribe
2*nObj in len – can be the output from EG_intersection.
- result** the returned resultant Body Object (with the same type as **src**),
though the splitting of Face Body Object results in a SHEETBODY
- icode** the integer return code

Imprints Edge/Loop Objects on the source Body Object (that has the type SOLIDBODY, SHEETBODY or FACEBODY). The Edge/Loop Objects are paired with the Faces in the source that will be scribed.

Note: Under rare circumstance this may fail and return the indication of success [especially after seeing the message: *EGADS Info: splitBody = xx – using OpenCASCADE (EG_imprintBody)!.*

If appropriate, you may want to consider using the SPLITTER operation of EG_generalBoolean.

Fillet a Body

```
icode = EG_filletBody(ego src, int nEdge, ego *edges, double radius,
                      ego *result, int **maps);
icode = IG_filletBody(I*8 src, I*4 nEdge, I*8 edges, R*8 radius,
                      I*8 result, CPTR maps)
result, map = src.filletBody(edges, radius)
result, map = filletBody(src::Ego, edges::Ego[], radius::Float)
```

- src** the source Body Object
- nEdge** the number of Edge Objects to fillet
- edges** pointer to a list of Edges to fillet – **nEdge** in len
- radius** the radius of the fillets created
- result** the resultant Body Object (with the same type as **src**)
- maps** the returned pointer to a list of Face mappings (in **result**) which includes operations (see page 13) and an index in **src** where the Face originated – $2 * (\text{number of Faces in result})$ in length (freeable)
- icode** the integer return code

Fillets the Edges on the source Body Object (that has the type SOLIDBODY or SHEETBODY).

Chamfer a Body

```

icode = EG_chamferBody(ego src, int nEdge, ego *edges, ego *faces,
                      double dis1, double dis2, ego *result,
                      int **maps);

icode = IG_chamferBody(I*8 src, I*4 nEdge, I*8 edges, I*8 faces,
                      R*8 dis1, R*8 dis2, I*8 result,
                      CPTR maps)

result, map = src.chamferBody(edges, faces, dis1, dis2)
result, map = chamferBody(src::Ego, edges::Ego[], faces::Ego[],
                          dis1::Float, dis2::Float)

```

- src** the source Body Object
- nEdge** the number of Edge Objects to chamfer
- edges** pointer to a list of Edges to chamfer – **nEdge** in len
- faces** pointer to a list of Face Objects to to measure **dis1** from – **nEdge** in len
- dis1** the distance from the Face Object to chamfer
- dis2** the distance from the *other* Face Object to chamfer
- result** the resultant Body Object (with the same type as **src**)
- maps** the returned pointer to a list of Face mappings (in **result**) which includes operations (see page 13) and an index in **src** where the Face originated – $2 * (\text{number of Faces in } \text{result})$ in length (freeable)
- icode** the integer return code

Chamfers the Edges on the source Body Object (that has the type SOLIDBODY or SHEETBODY).

Hollow a Body

```
icode = EG_hollowBody(ego src, int nFace, ego *faces, double off,
                      int join, ego *result, int **maps);
icode = IG_hollowBody(I*8 src, I*4 nFace, I*8 faces, R*8 off,
                      I*4 join, I*8 result, CPTR maps)
result, map = src.hollowBody(faces, off, join)
result, map = hollowBody(src::Ego, faces::Ego([]), off::Float,
                          join::Int)
```

- src** the source Body Object (SOLIDBODY, SHEETBODY, FACEBODY or FACE*)
- nFace** the number of Face Objects to remove (0 performs an *offset*)
- faces** pointer to a list of FACE objects to remove – **nFace** in len
- off** the wall thickness (or offset) of the result
- join** 0 – fillet-like corners, 1 – expanded corners
- result** the resultant Body Object
- maps** the returned pointer to a list of Face mappings (in **result**) which includes operations (see page 13) and an index in **src** where the Face originated – $2 * (\text{number of Faces in result})$ in length (freeable)
- icode** the integer return code

A hollowed *solid* is built from an initial SOLIDBODY Object and a set of Faces that bound the *solid*. These Faces are removed and the remaining become the walls of the *hollowed solid* with the specified thickness. If there are no Faces specified then the Body is *offset* by **off** (which can be negative).

* Note: If **src** is a Face, then **faces** should be a list of Edges and the result will be a Face Object. **maps** in this case is not filled.

Revolve to create a Body

```
icode = EG_rotate(ego src, double angle, double *axis, ego *result);  
icode = IG_rotate(I*8 src, R*8 angle, R*8 axis, I*8 result)  
result = src.rotate(angle, axis)  
result = rotate(src::Ego, angle::Float, axis::Float[]([]))
```

- src** the source Body Object (not SHEETBODY or SOLIDBODY)
- angle** the angle to rotate the object through [0-360 Degrees]
- axis** pointer to a point (on the axis) and a direction (6 in length)
- result** the returned resultant Body Object (type is one higher than **src**)
- icode** the integer return code

Revolves the source Object about the axis through the angle specified. If the Object is either a Loop or WIREBODY the result is a SHEETBODY. If the source is either a Face or FACEBODY then the returned Body Object is a SOLIDBODY.

Extrude to create a Body

dot

```
icode = EG_extrude(ego src, double dist, double *dir, ego *result);  
icode = IG_extrude(I*8 src, R*8 dist, R*8 dir, I*8 result)  
result = src.extrude(dist, dir)  
result = extrude(src::Ego, dist::Float, dir::Float[])
```

src the source Body Object (not SHEETBODY or SOLIDBODY)

dist the distance to extrude

dir pointer to the vector that is the extrude direction (3 in length)

result the returned resultant Body Object (type is one higher than **src**)

icode the integer return code

Extrudes the source Object through the distance and direction specified. If the Object is either a Loop or WIREBODY the result is a SHEETBODY. If the source is either a Face or FACEBODY then the returned Body Object is a SOLIDBODY.

Sweep to create a Body

```
icode = EG_sweep(ego src, ego spine, int mode, ego *result);
icode = IG_sweep(I*8 src, I*8 spine, I*4 mode, I*8 result)
result = src.sweep(spine, mode)
result = sweep(src::Ego, spine::Ego, mode::Int)
```

src the source Body Object (not SHEETBODY or SOLIDBODY)

spine the Object used as guide curve segment(s) to sweep the source through

mode sweep mode:

0	Corrected Frenet	5	Guide AC
1	Fixed	6	Guide Plan
2	Frenet	7	Guide AC With Contact
3	Constant Normal	8	Guide Plan With Contact
4	Darboux	9	Discrete Trihedron

result the returned resultant Body Object (type is one higher than **src**)

icode the integer return code

Sweeps the source Object through the “spine” specified. The spine can be either an Edge, Loop or WIREBODY Object. If the source Object is either a Loop or WIREBODY the result is a SHEETBODY. If the source is either a Face or FACEBODY then the returned Object is a SOLIDBODY.

Note: this does not always work as expected...

Lofts through sections to create a Body – Deprecated

```
icode = EG_loft(int nSection, ego *sections, int option, ego *result);  
icode = IG_loft(I*4 nSection, I*8 sections, I*4 option, I*8 result)
```

- nSection** the number of Sections in the Loft Operation
- sections** pointer to a list of WIREBODY or Loop Objects to Loft – **nSection** in len
the first and last can be Node Objects
- option** bit flag that controls the loft:
1 – SOLIDBODY result (default is SHEETBODY)
2 – Ruled (linear) Loft (default is smooth)
- result** the resultant Body Object
- icode** the integer return code

Lofts the input Objects to create a Body Object (that has the type SOLIDBODY or SHEETBODY).

Please use either `EG_blend` (page 151) or `EG_ruled` (page 150).

Linearly lofts through sections to create a Body

dot

```
icode = EG_ruled(int nSection, ego *sections, ego *result);  
icode = IG_ruled(I*4 nSection, I*8 sections, I*8 result)  
result = egads.ruled(sections)  
result = ruled(sections::Ego)
```

nSection the number of Sections in the *rule* Operation

note: interior repeated sections are ignored

sections a list of FACEBODY, Face, WIREBODY or Loop Objects (**nSection** in len)

FACEBODY/Faces must have only a single Loop; all or the first and last sections can be Nodes; if the first/last are Nodes and/or FACEBODY/Faces (and the internal sections are CLOSED) the result will be a SOLIDBODY otherwise it will be a SHEETBODY; if the first and last sections contain equivalent Loops (and all sections are CLOSED) a periodic (torus-like) SOLIDBODY is created

result the resultant Body Object

icode the integer return code

Produces a Body Object (that has the type SOLIDBODY or SHEETBODY) that goes through the sections by *ruling* surfaces between each. All sections must have the same number of Edges (except for Nodes) and the Edge order in each is used to specify the connectivity. An exception is when the attribute “multiNode” is found on Nodes in the Loop, which needs to be numeric and indicates the multiplicity of the Node [creating Degenerate Edge(s) in the result]. If this is the case, the number of Edges and the sum of the Node multiplicities must be the same for each section. There is a special case when the attributed Node is the first in the Loop and the Loop is closed: a second numeric value is required in the attribute where this one indicates the the start – 0 is all degenerates are at the start, and if the number of multiples then the start is the Edge itself, where the degenerates end up at the end of the Loop.

Note: for both EG_blend and EG_ruled: all Loops must have their Edges ordered in a CCW (counterclockwise) manner.

Lofts through sections to create a Body

dot

```
icode = EG_blend(int nSection, ego *sections, double *rc1,
                double *rc2, ego *result);
icode = IG_blend(I*4 nSection, I*8 sections, R*8 rc1,
                R*8 rc2, I*8 result)
result = egads.blend(sections, rc1=None, rc2=None)
result = blend(sections::Ego[]; rc1::Float[], rc2::Float[])
```

nSection the number of Sections in the *blend* Operation

sections a list of FACEBODY, Face, WIREBODY or Loop Objects (**nSection** in len)
 FACEBODY/Faces must have only a single Loop; all or the first and last sections can be Nodes; if the first/last are Nodes and/or FACEBODY/Faces (and the internal sections are CLOSED) the result will be a SOLIDBODY otherwise it will be a SHEETBODY; if the first and last sections contain equivalent Loops (and all sections are CLOSED) a periodic (C^0 at closure) SOLIDBODY is created.
 Interior sections are C^2 and can be repeated once[†] for C^1 or twice for C^0

rc1 specifies treatment[‡] at the first section (or **NULL** for no treatment)

rc2 specifies treatment[‡] at the last section (or **NULL** for no treatment)

result the resultant Body Object

Lofts the input Objects to create a Body Object (that has the type SOLIDBODY or SHEETBODY). Cubic BSplines are used. All sections must have the same number of Edges (except for single Nodes) and the Edge order in each (in a CCW manner) is used to set the connectivity.

[†] section attribute .C1side set to “Fwd” or “rev” overrides the default side to compute the C^1 tangency.

[‡] for Nodes – elliptical treatment (8 in length): radius of curvature1, unit dir, radius of curvature2, orthogonal dir (**nSection** must be at least 3 or 4 for treatments at both ends); for other sections – setting tangency (4 in length): magnitude, unit direction; for Faces with 2 or 3 Edges in the Loop – make a *Wing Tip-like* cap: zero, growthFactor (length of 2).

Initialize *Effective Topology* Body

ET

```
icode = EG_initEBody(ego tess, double angle, ego *ebody);  
icode = IG_initEBody(I*8 tess, R*8 angle, I*8 ebody)  
ebody = tess.initEBody(angle)  
ebody = initEBody(tess::Ego, angle::Float)
```

- tess** the input Solid or Sheet Body Tessellation Object (can be quite coarse)
- angle** angle used to determine if Nodes on open Edges of Sheet Bodies can be removed. The dot of the tangents at the Node is compared to this angle (in degrees). If the dot is greater than the angle, the Node does not disappear. The angle is also used to test Edges to see if they can be removed. Edges with normals on both trimmed Faces showing deviations greater than the input angle will not disappear. Valid range 0.0 to 90.0 and should be closer to zero.
- ebody** the resultant Open *Effective Topology* Body Object
- icode** the integer return code

Takes as input a Body Tessellation Object and returns an Open EBody fully initialized with *Effective Objects* (that may only contain a single *non-effective* object). EEdges are automatically merged where possible (removing Nodes that touch 2 Edges, unless degenerate or marked as “.Keep”). The tessellation is used (and required) in order that single UV space be constructed for EFaces.

Construct EFaces using an Attribute

ET

```

icode = EG_makeAttrEFaces(ego ebody, const char *attrName,
                           int *nface, ego **efaces);
icode = IG_makeAttrEFaces(I*8 ebody, C** attrName,
                           I*4 nface, I*8 efaces)
efaces = ebody.makeAttrEFaces(attrName)
efaces = makeAttrEFaces(ebody::Ego, attrName::String)

```

- ebody** the input Open *Effective Topology* Body Object
- attrName** the attribute name used to collect Faces into an EFaces. The attribute value(s) are then matched to make the collections.
- nface** the returned number of constructed EFaces
- efaces** the returned pointer to a list of EFaces constructed (freeable) – may be **NULL**
- icode** the integer return code

Modifies the EBody by finding “free” Faces (a single Face in an EFace) with **attrName** and the same attribute value(s), thus making a collection of EFaces. All attributes matching in the collection of Faces are moved to the EFace(s) (at a minimum **attrName** will persist) unless in “Full Attribute” mode, which then performs attribute merging. This function returns the number of EFaces possibly constructed (**nface**). The *UVbox* can be retrieved via calls to either `EG_getTopology` (page 90) or `EG_getRange` (page 81) with the returned appropriate **efaces**.

Note: triangulations must *touch* to be within an EFace.

Construct an EFace

ET

```

icode = EG_makeEFace(ego ebody, int nface, ego *faces, ego *eface);
icode = IG_makeEFace(I*8 ebody, I*4 nface, I*8 faces, I*8 eface)
eface = ebody.makeEFace(faces)
eface = makeEFace(ebody::Ego, faces::Ego([]))

```

ebody the input Open *Effective Topology* Body Object
nface the number of Face Objects in **faces**
faces the list of Face Objects used to make **eface** (**nface** in length)
eface the returned constructed EFace Object now in **ebody**
icode the integer return code

Modifies the EBody by removing the **nface** “free” Faces and constructing a single **eface** (returned for convenience – the **ebody** is updated). All attributes matching in **faces** are moved to **eface** unless the “Full Attribution” mode is in place. This constructs a single UV for the **faces**. The *UVbox* can be retrieved via calls to EG_getTopology (page 90) or EG_getRange (page 81) with **eface**.

Finish an EBody

ET

```

icode = EG_finishEBody(ego ebody);
icode = IG_finishEBody(I*8 ebody)
ebody.finishEBody()
finishEBody!(ebody::Ego)

```

ebody the input Open *Effective Topology* Body Object that will be Closed

Parameter/Object Lookup

ET, E1

```
icode = EG_effectiveMap(ego eobj, double *eparam, ego *obj,
                        double *param);
icode = IG_effectiveMap(I*8 eobj, R*8      eparam, I*8  obj,
                        R*8      param)
obj, param = eobj.effectiveMap(eparam)
obj, param = effectiveMap(eobj::Ego, eparam::Float([]))
```

- eobj** the input *Effective Topology* Object (either EEdge or EFace)
- eparam** t for EEdges / the $[u, v]$ for an EFace
- obj** the returned source Object in the Body
- param** the returned t for an Edge / the returned $[u, v]$ for the Face
- icode** the integer return code

Returns the evaluated location in the BRep for the *Effective Topology* entity.

Returns details of an EEdge

ET, E1

```

icode = EG_effectiveEdgeList(ego edge, int *nedge, ego **edges,
                             int **senses, double **tstart);
icode = IG_effectiveEdgeList(I*8 edge, I*4 nedge, I*8 edges,
                             I*4 senses, R*8 tstart)

edges, senses, tstart = eedge.effectiveEdgeList()
edges, senses, tstart = effectiveEdgeList(eedge::Ego)

```

- eedge** the *Effective Topology* Edge Object
- nedge** the returned number of Edges in **eedge** and others
- edges** the returned pointer to a list of Edges – **nedge** in length (freeable)
- senses** the returned pointer to a list of senses – **nedge** in length (freeable)
- tstart** the returned pointer to a list of t starting values – **nedge** in length (freeable)
- icode** the integer return code

Returns the list of Edge entities in the source Body that make up the EEdge. A pointer to an integer list of senses for each Edge is returned as well as the starting t value in the EEdge (remember that the t will go in the opposite direction in the Edge if the sense is SREVERSE).

EG_addKnots	78	EG_fitTriangles	77
EG_alloc	63	EG_flipObject	57
EG_approximate	76	EG_free	63
EG_arcLength	81	EG_fuseSheets	140
EG_attributeAddSeq	70	EG_generalBoolean	139
EG_attributeAdd	64	EG_getArea	98
EG_attributeDel	65	EG_getBodyTopos	96
EG_attributeDup	68	EG_getBody	105
EG_attributeGet	67	EG_getBoundingBox	98
EG_attributeNumSeq	71	EG_getContext	61
EG_attributeNum	65	EG_getEdgeUV	101
EG_attributeRetSeq	72	EG_getGeometry	74
EG_attributeRet	66	EG_getGlobal	135
EG_blend	151	EG_getInfo	60
EG_calloc	63	EG_getMassProperties	99
EG_chamferBody	144	EG_getPatch	126
EG_close	52	EG_getQuads	125
EG_contextCopy	59	EG_getRange	81
EG_convertToBSpline	86	EG_getTessEdge	120
EG_convertToBSplineRange	87	EG_getTessFace	121
EG_copyObject	58	EG_getTessGeom	113
EG_curvature	84	EG_getTessLoops	122
EG_deleteEdgeVert	127	EG_getTessQuads	124
EG_deleteObject	52	EG_getTolerance	105
EG_effectiveEdgeList	156	EG_getTopology	90
EG_effectiveMap	155	EG_getTransform	57
EG_evaluate	82	EG_getWindingAngle	111
EG_exportModel	62	EG_hollowBody	145
EG_extrude	147	EG_importModel	62
EG_filletBody	143	EG_imprintBody	142
EG_finishEBody	154	EG_inFace	100
EG_finishTess	134	EG_inTopology	100

EG_indexBodyTopo	97	EG_matchBodyEdges	107
EG_initEBody	152	EG_matchBodyFaces	108
EG_initTessBody	129	EG_mergeBSplineCurves	86
EG_insertEdgeVert	128	EG_moveEdgeVert	127
EG_intersection	141	EG_objectBodyTopo	97
EG_invEvaluate	83	EG_openTessBody	129
EG_isEquivalent	99	EG_open	51
EG_isIsoPCurve	80	EG_otherCurve	85
EG_isSame	85	EG_quadTess	116
EG_isoCline	79	EG_reall	63
EG_loadModel	53	EG_remakeTess	117
EG_loadTess	137	EG_replaceFaces	103
EG_localToGlobal	135	EG_revision	51
EG_locateTessBody	119	EG_rotate	146
EG_loft	149	EG_ruled	150
EG_makeAttrEFaces	153	EG_saveModel	54
EG_makeEFace	154	EG_saveTess	137
EG_makeFace	92	EG_setFullAttrs	68
EG_makeGeometry	73	EG_setOutLevel	61
EG_makeLoop	93	EG_setTessEdge	131
EG_makeNmWireBody	95	EG_setTessFace	132
EG_makeQuads	123	EG_setTolerance	106
EG_makeSolidBody	94	EG_sewFaces	102
EG_makeTessBody	114	EG_skinning	75
EG_makeTessGeom	112	EG_solidBoolean	138
EG_makeTopology	89	EG_statusTessBody	130
EG_makeTransform	56	EG_strdup	63
EG_mapBody	109	EG_sweep	148
EG_mapBody2	110	EG_tessMassProperties	136
EG_mapTessBody	118	EG_tolerance	106
		EG_updateThread	56