



The EGADS Derivative API
Engineering Geometry Aircraft Design System
at ESP Revision 1.29

Marshall Galbraith & Bob Haines
galbramc@mit.edu haines@mit.edu
Aerospace Computational Design Lab
Department of Aeronautics & Astronautics
Massachusetts Institute of Technology

● Overview	3
● EGADS API	
● Geometry_dot	4
● Topology_dot	14
● Tessellation_dot	18
● Top-Down Build Functions	19
● API Index	23

Provide geometric parameter sensitivities

- Bottom-up geometry construction fully differentiated
 - Sensitivities stored in `ego` objects
 - Configuration sensitivities computed with discrete evaluation
- EGADS geometry routines differentiated with operator overloaded automatic differentiation

Set a Geometry Object's sensitivity

```
icode = EG_setGeometry_dot(ego object, int oclass, int mtype,
                           const int *ints, const double *reals,
                           const double *reals_dot);
icode = IG_setGeometry_dot(I*8 context, I*4 oclass, I*4 mtype,
                           I*4          ints, R*8          reals,
                           R*8          reals_dot)
geom.setGeometry_dot(oclass, mtype, reals, reals_dot, ints=None)
```

- object** the Geometry Object: NODE, CURVE, or SURFACE
- oclass** the Object Class associated with the reals
- mtype** the Member Type associated with the reals (depends on oclass)
- ints** the integer information (if none use **NULL**)
- reals** the original real data used to construct the geometry (cannot be retrieved with EG_getGeometry)
- reals_dot** the sensitivity of the reals to set in the object
- icode** the integer return code

Notes: ints is required for either mtype = BEZIER or BSPLINE.

Calling EG_setGeometry_dot with ints, reals & reals_dot set to **NULL** clears the object of all sensitivities (oclass and mtype may be 0).

Create a Geometry Object with sensitivities

```

icode = EG_makeGeometry_dot(ego context, int oclass, int mtype,
                           ego rGeom, const int *ints,
                           const double *reals, const double *reals_dot, ego *nGeom);
icode = IG_makeGeometry_dot(I*8 context, I*4 oclass, I*4 mtype,
                           I*8 rGeom, I*4      ints,
                           R*8      reals, R*8      reals_dot, I*8  nGeom)
nGeom = context.makeGeometry_dot(oclass, mtype, reals, reals_dot,
                                ints=None, geom=None)

```

context the Context Object

oclass the Object Class: PCURVE, CURVE or SURFACE

mtype the Member Type (depends on oclass)

rGeom the reference Geometry Object (if none use **NULL**)

ints the integer information (if none use **NULL**)

reals the real data used to construct the geometry

reals_dot the sensitivity of the real data

nGeom the returned pointer to the new Geometry Object

icode the integer return code

Notes: This is equivalent to calling EG_makeGeometry followed by EG_setGeometry_dot.

Return a Geometry Object's sensitivities

```
icode = EG_getGeometry_dot(ego object,  
                           double **reals, double **reals_dot);  
icode = IG_getGeometry_dot(I*8 object,  
                           R*8      reals, R*8      reals_dot)  
reals, reals_dot = object.getGeometry_dot()
```

object the Geometry Object with sensitivities: NODE, CURVE, or SURFACE

reals the returned pointer to real data used to describe the geometry (*freeable*)

reals_dot the returned pointer to sensitivity of the real data (*freeable*)

icode the integer return code

Query an Object's sensitivities

```
icode = EG_hasGeometry_dot(ego object);  
icode = IG_hasGeometry_dot(I*8 object)  
bool = object.hasGeometry_dot()
```

object the Object to query

icode the integer return code (populated is EGADS_SUCCESS, missing sensitivities is EGADS_NOTFOUND)

Notes: Checks if all entities in the object hierarchy are populated with sensitivity information

Copy and optionally Transform the Object's sensitivities

```
icode = EG_copyGeometry_dot(const ego object,
                           double* mat, double* mat_dot, ego copy);
icode = IG_copyGeometry_dot(I*8 object,
                           I*8 mat, I*8 mat_dot, I*8 copy)
object.copyGeometry_dot(copy, mat=None, mat_dot=None)
```

- object** the Object to copy sensitivities from
- mat** the 12 values of the translation/rotation matrix, **NULL** for a strict copy
- mat_dot** the sensitivities of mat, may be **NULL** for mat without sensitivities
- copy** the Object populated with the copied sensitivities
- icode** the integer return code

Note: The mat transformation should be consistent with what was used for EG_copyObject to create the “copy” Object

Zero out an Object's sensitivities

```
icode = EG_zeroGeometry_dot(ego object);
icode = IG_zeroGeometry_dot(I*8 Object)
object.zeroGeometry_dot()
```

- object** the Geometry or Topology Object
- icode** the integer return code

Evaluate with sensitivities on an Object

```
icode = EG_evaluate_dot(ego object,  
                        double *params, double *params_dot,  
                        double *result, double *result_dot);  
icode = IG_evaluate_dot(I*8 object,  
                        R*8      params, R*8      params_dot,  
                        R*8      result, R*8      result_dot)  
result, result_dot = object.evaluate_dot(params, params_dot)
```

object the input Object

params NODE – ignored (can be **NULL**); CURVE, EDGE, EEDGE – the t value
SURFACE, FACE, EFACE – u then v

params_dot the params sensitivity, may be **NULL** for params without sensitivities

result the returned position, 1st and 2nd derivatives (see EG_evaluate)

result_dot the returned position, 1st and 2nd derivatives sensitivities

icode the integer return code

Inverse evaluation on the Object with sensitivities

```

icode = EG_invEvaluate_dot(ego object, double *pos, double *pos_dot,
                           double *params, double *params_dot,
                           double *result, double *result_dot);
icode = IG_invEvaluate_dot(I*8 object, R*8      pos, R*8      pos_dot,
                           R*8      params, R*8      params_dot,
                           R*8      result, R*8      result_dot)
params, params_dot, result, result_dot = object.invEvaluate_dot(pos)

```

object the input Object

pos is $[u, v]$ for a PCURVE and $[x, y, z]$ for all others

pos_dot the pos sensitivity (may be **NULL**)

params the returned parameter(s) found for the nearest position on the Object:
 for PCURVE, CURVE, EDGE or EEDGE the one value is t
 for SURFACE, FACE or EFACE the 2 values are u then v

params_dot the returned sensitivity of params

result the closest position found is returned:
 $[u, v]$ for a PCURVE (len = 2)
 $[x, y, z]$ for all others (len = 3)

result_dot the returned sensitivity of result

icode the integer return code

Populate a *skinning* Surface with sensitivities

```
icode = EG_skinning_dot(ego object, int nCurve, ego *curves);  
icode = IG_skinning_dot(I*8 object, I*4 nCurve, I*8 curves)  
    object.skinning_dot(curves)
```

object the *skinned* BSpline surface

nCurve the number of BSpline curves

curves the vector of **ego** curves used to create the *skinned* surface (populated with sensitivity information)

icode the integer return code

Populate an *approximated* Object with sensitivities

```
icode = EG_approximate_dot(ego bspline, int mDeg, double tol,
                           const int *sizes, const double *xyzs,
                           const double *xyzs_dot);
icode = IG_approximate_dot(I*8 bspline, I*4 mDeg, R*8 tol,
                           I*4          sizes, R*8          xyzs,
                           R*8          xyzs_dot)
bspline.approximate_dot(sizes, xyzs, xyzs_dot,
                        mDeg=0, tol=1.e-8)
```

- bspline** the B-spline Object created with approximate
- mDeg** the boundary condition used by EGADS [0-2], must be consistent with value used to create bspline
- tol** this is the tolerance to use for the BSpline approximation procedure, must be consistent with value used to create bspline
- sizes** a vector of 2 integers that specifies the size and dimensionality of the data. If the second is zero, then a CURVE is fit and the first integer is the length of the number of $[x, y, z]$ triads. If the second integer is nonzero, then the input data reflects a 2D map.
- xyzs** the data to fit (3 times the number of points in length)
- xyzs_dot** the sensitivity of xyzs
- icode** the integer return code

Create a Topology Object with sensitivities

```

icode = EG_makeTopology_dot(ego context, ego geom, int oclass,
                           int mtype, double *reals, double *reals_dot,
                           int nchild, ego *children, int *senses, ego *topo);
icode = IG_makeTopology_dot(I*8 context, I*8 geom, I*4 oclass,
                           I*4 mtype, R*8      reals, R*8      reals_dot,
                           I*4 nchild, I*8  children, I*4  senses, I*8  topo)
topo = context.makeTopology_dot(oclass, mtype=0, geom=None,
                               reals=None, reals_dot=None, children=None, senses=None)

```

context the Context Object
geom the reference Geometry Object (if none use **NULL**)
oclass the Object Class: NODE, EDGE, LOOP, FACE, SHELL, BODY or MODEL
mtype the Member Type (depends on **oclass** – see EGADS API doc)
reals the real data: may be **NULL** except for NODE or EDGE
reals_dot the sensitivity of the real data: cannot be **NULL** for NODE or EDGE
nchild number of children (lesser) Topological Objects
children vector of children objects (**nchild** in length) with sensitivities
senses a vector of integer senses for the children (required for FACES & LOOPS only)
topo the returned pointer to the new Topology Object with sensitivities
icode the integer return code

Note: EG_makeTopology will also preserve sensitivities in Children

Query a Topology Object

```

icode = EG_getTopology_dot(ego topo, ego *geom, int *oclass,
                           int *mtype, double *reals, double *reals_dot,
                           int *nchild, ego **children, int **senses);
icode = IG_getTopology_dot(I*8 topo, I*8 geom, I*4 oclass,
                           I*4 mtype, R*8 reals, R*8 reals_dot,
                           I*4 nchild, I*8 children, I*4 senses)
oclass,mtype,geom,reals,reals_dot,children,senses = topo.getTopology_dot()

```

- topo** the Topology or *Effective Topology* Object to query
- geom** the returned reference Geometry Object (can be **NULL**)
- oclass** the returned Object Class: Topology or *Effective Topology*
- mtype** the returned Member Type (depends on **oclass**)
- reals** the real data (at most 4 **double**s are filled): **NODE** – contains the $[x, y, z]$ location, **EDGE** where the t_{min} and t_{max} (the parametric bounds) are returned and **FACE** where the $[u, v]$ box is filled → the limits first for u then for v (4 in length)
- reals_dot** the returned parametric sensitivity of reals
- nchild** the returned number of children (lesser) Topological Objects
- children** the returned pointer to a vector of children objects (**nchild** in length)
 - if a **LOOP** with a reference **SURFACE**, then $2 * \text{nchild}$ in length (PCurves follow)
 - if a **MODEL** – **nchild** is the number of Body Objects, **mtype** the total **ego** count
- senses** a vector of senses for the children (**LOOPS**) or inner/outer for (**FACES** & **SHELLS**)
- icode** the integer return code (EGADS_OUTSIDE for an open EBody)

Set range sensitivity

```
icode = EG_setRange_dot(ego object, int oclass,  
                        double *range, double *range_dot);  
icode = IG_setRange_dot(I*8 object, I*4 oclass,  
                        R*8 range, R*8 range_dot)  
object.setRange_dot(range, range_dot)
```

object the input Object (EDGE)

oclass the Object Class associated with the range

range EDGE – 2 vales are filled: t_{start} and t_{end}

range_dot the sensitivity for range

icode the integer return code

Returns the range sensitivity and periodicity

```
icode = EG_getRange_dot(ego object, double *range, double *range_dot,
                        int *periodic);
icode = IG_getRange_dot(I*8 object, R*8 range, R*8 range_dot,
                        I*4 periodic)
range, range_dot, periodic = object.getRange_dot()
```

object the input Object (EDGE)

range EDGE – 2 vales are filled: t_{start} and t_{end}

range_dot the sensitivity for range

periodic 0 for non-periodic, 1 for periodic in t or u , 2 for periodic in v (or-able)

icode the integer return code

Populate a simple Solid Body /w Sensitivities – Incomplete

```
icode = EG_makeSolidBody_dot(ego body, int stype, const double *data,
                             const double *data_dot);
icode = IG_makeSolidBody_dot(I*8 body, I*4 stype, R*8 data,
                             R*8 data_dot)
body.makeSolidBody_dot(stype, data, data_dot)
```

body the Object created with makeSolidBody

stype one of: BOX, SPHERE, CONE, CYLINDER, TORUS

data length and fill depends on stype:

BOX	6	$[x, y, z]$ then $[dx, dy, dz]$ for the size of box
SPHERE	4	$[x, y, z]$ of center then the radius
CONE	7	apex $[x, y, z]$, base center $[x, y, z]$, then the radius
CYLINDER	7	2 axis points and the radius
TORUS	8	$[x, y, z]$ of center, direction of rotation, then the major radius and minor radius

data_dot the sensitivities of data

icode the integer return code

Populate a Face Object with sensitivities

```
icode = EG_makeFace_dot(ego face, ego object,  
                        const double *rdata, const double *rdata_dot);  
icode = IG_makeFace_dot(I*8 face, I*8 object,  
                        R*8 rdata, R*8 rdata_dot)
```

`face.makeFace_dot(object, rdata=None, rdata_dot=None)`

face the resultant returned topological Face Object created with EG_makeFace

object the Loop populated with sensitivities that was used with EG_makeFace

rdata may be **NULL** for Loops

rdata_dot the sensitivity of rdata

icode the integer return code

Returns the Discrete Mass Properties with sensitivities

```
icode = EG_tessMassProps_dot(const ego tess, double *xyzs_dot,
                             double *props, double *props_dot);
icode = IG_tessMassProps_dot(I*8      tess, R*8      xyzs_dot,
                             R*8      props, R*8      props_dot)
volume, volume_dot, aeraOrLen, aeraOrLen_dot, CG, CG_dot, I, I_dot
= tess.tessMassProps(xyzs_dot=None)
```

tess the Body Tessellation Object used to compute the Mass Properties

xyzs_dot sensitivities of xyzs on the Tessellation Object (evaluate from body if **NULL**)

props 14 **double**s filled reflecting Volume, Area (or Length), Center of Gravity (3) and the inertia matrix at CG (9)

props_dot 14 **double**s with sensitivities of props

icode the integer return code

Computes and returns the physical and inertial properties of a Tessellation Object.

Populate a *Revolved* Body with sensitivities – Incomplete

```
icode = EG_rotate_dot(ego body, const ego src,  
                      double angle, double angle_dot,  
                      double *axis, double *axis_dot);  
icode = IG_rorate_dot(I*8 body, I*8      src,  
                      R*8      angle, R*8      angle_dot,  
                      R*8      axis,  R*8      axis_dot)  
object.rotate_dot(src, angle, angle_dot, axis, axis_dot)
```

body the Body Object created with rotate

src the source Object (populated with sensitivities) used to create body

angle the angle used to rotate the object through [0-360 Degrees]

angle_dot the angle sensitivity

axis pointer to a point (on the axis) and a direction (6 in length)

axis_dot pointer to a axis sensitivities (6 in length)

icode the integer return code

Populate an *Extruded* Body with sensitivities – Incomplete

```
icode = EG_extrude_dot(ego body, const ego src,  
                      double dist, double dist_dot,  
                      double *dir, double *dir_dot);  
icode = IG_extrude_dot(I*8 body, I*8      src,  
                      R*8      dist, R*8      dist_dot,  
                      R*8      dir, R*8      dir_dot)  
body.extrude_dot(src, dist, dist_dot, dir, dir_dot)
```

body the Body Object created with extrude
src the source Object (populated with sensitivities) used to create body
dist the distance to extrude
dist_dot the distance sensitivity
dir pointer to the vector that is the extrude direction (3 in length)
dir_dot dir sensitivity (3 in length)
icode the integer return code

Populates a *Ruled* Body with Sensitivities

```
icode = EG_ruled_dot(ego body, int nSection, ego *sections);  
icode = IG_ruled_dot(I*8 body, I*4 nSection, I*8 sections)  
    body.ruled_dot(sections)
```

- nSection** the number of Sections in the *rule* Operation
interior repeated sections are ignored
- sections** the array of sections (populated with sensitivities) used to create the *rule* body
- icode** the integer return code

Populates a *Blended* Body with Sensitivities

```
icode = EG_blend_dot(ego body, int nSection, ego *sections,  
                    double *rc1, double *rc1_dot,  
                    double *rc2, double *rc2_dot);  
icode = IG_blend_dot(I*4 nSection, I*8 sections,  
                    R*8 rc1, R*8 rc1_dot,  
                    R*8 rc2, R*8 rc2_dot)  
    body.blend_dot(sections, rc1=None, rc1_dot=None,  
                  rc2=None, rc2_dot=None)
```

- body** the Body Object created with the *blend* Operation
- nSection** the number of Sections in the *blend* Operation
interior sections can be repeated once for C^1 or twice for C^0
- sections** the array of sections (populated with sensitivities) used to create the *rule* body
- rc1** specifies treatment at the first section (or **NULL** for no treatment)
- rc1_dot** sensitivity of rc1
- rc2** specifies treatment at the last section (or **NULL** for no treatment)
- rc2_dot** sensitivity of rc2
- icode** the integer return code

EG_approximate_dot	11
EG_blend_dot	22
EG_copyGeometry_dot	7
EG_evaluate_dot	8
EG_invEvaluate_dot	9
EG_extrude_dot	20
EG_getGeometry_dot	6
EG_getRange_dot	15
EG_hasGeometry_dot	6
EG_makeFace_dot	17
EG_makeGeometry_dot	5
EG_makeSolidBody_dot	16
EG_makeTopology_dot	12
EG_getTopology_dot	13
EG_rotate_dot	19
EG_ruled_dot	21
EG_setGeometry_dot	4
EG_setRange_dot	14
EG_skinning_dot	10
EG_tessMassProp_dot	18
EG_zeroGeometry_dot	7